

**Digital Television Transition Notice:**

This device contains a digital television tuner, so it should receive digital over the air TV programming, with a suitable antenna, after the end of full-power analog TV broadcasting in the United States on February 17, 2009. Some older television receivers, if they rely on a TV antenna, will need a TV Converter to receive over the air digital programming, but should continue to work as before for other purposes (e.g., for watching low-power TV stations still broadcasting in analog, watching pre-recorded movies, or playing video games).

For more information, call the FCC at 1-888-CALL-FCC (1-888-225-5322) or see www.DTV.gov. For information on the TV Converter program, and on government coupons that may be used toward the purchase of one, see www.dtv2009.gov, or call the NTIA at 1-888-DTV-2009.

Aviso Relativo A La Transición A Televisión Digital:



Este equipo incorpora un sintonizador de televisión digital, lo que le permitirá recibir una programación digital televisada por aire, con una antena adecuada, cuando se terminará la transmisión de alta potencia de la televisión analógica en los Estados Unidos el 17 de febrero de 2009. Ciertos receptores de televisión antiguos, si dependen de una antena de TV, necesitarán un conversor de TV para recibir por el aire una programación digital, pero seguirán funcionando como antes para otros usos (por ejemplo para ver emisoras de TV de baja potencia que todavía transmiten en analógico, para ver películas pregrabadas, o para utilizar sus videojuegos).

Para obtener más información, llame FCC 1-888-CALL-FCC (1-888-225-5322) o refiérase a www.DTV.gov. Para toda información sobre el programa de conversores de TV, y acerca de los cupones del gobierno que se pueden usar para comprarlos, refiérase a www.dtv2009.gov, o llame al NTIA al 1-888-DTV-2009.

TABLE OF CONTENTS

FOR YOUR SAFETY	3
PRECAUTIONS AND REMINDERS	4
IMPORTANT SAFETY INSTRUCTIONS	6
PREPARATION	8
PERIPHERAL CONNECTION GUIDE	10
OPERATING INSTRUCTIONS	11
TO USE THE FRONT PANEL CONTROL	11
TO USE THE REMOTE CONTROL	12
TO USE THE MENUS	13
SETUP MENU	13
VIDEO MENU	14
AUDIO MENU	15
FEATURE MENU	16
TIPS	20
PRODUCT SPECIFICATION	22
BEFORE CALLING SERVICE	24
GLOSSARY	25
APPENDIX	26

English

SYMBOL	SYMBOL DEFINITION
 SA 1965	DANGEROUS VOLTAGE: The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electrical shock to persons.
 SA 1966	INSTRUCTIONS: The exclamation point within an equilateral triangle to alert the User to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, Such as vases, Shall be placed on the apparatus.

Caution - Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.

FOR YOUR SAFETY

Before operating the TV please read this manual thoroughly. This manual should be retained for future reference.

FCC Class B Radio Frequency Interference Statement

WARNING: (FOR FCC CERTIFIED MODELS)

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.


NOTICE

1. The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
2. Shielded interface cables and AC power cord, if any, must be used in order to comply with the emission limits.
3. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modification to this equipment. It is the responsibilities of the user to correct such interference.







WARNING:

To prevent fire or shock hazard, do not expose the TV to rain or moisture. Dangerously high voltages are present inside the TV. Do not open the cabinet. Refer servicing to qualified personnel only.


SAFETY: Lamp Disposal

 LAMP(S) INSIDE THIS PRODUCT CONTAIN MERCURY AND MUST BE RECYCLED OR DISPOSED OF ACCORDING TO LOCAL, STATE OR FEDERAL LAWS. FOR MORE INFORMATION, CONTACT THE ELECTRONIC INDUSTRIES ALLIANCE AT WWW.EIAE.ORG.


PRECAUTIONS AND REMINDERS

<p>Place unit on even surfaces.</p> 	<p>Don't place the TV in confined spaces or in a box when using it.</p> 
 <p>Unplug immediately if is malfunction like no picture, no video/audio, smoke and bad odor from TV.</p>	 <p>Unplug immediately if other foreign materials are put inside TV box or if the TV fell down.</p>
 <p>Don't throw any object inside the TV box like metals or other flammable materials.</p>	 <p>Prohibit/Avoid opening TV cabinet</p>


Remember to unplug the AC cord from the AC outlet before cleaning. Do not use liquid cleaners or aerosol cleaners to clean the display.



Avoid direct sunlight, dusty, high humidity and smoky areas.




Make sure to unplug the unit when not in use for a long period of time (days).




Call service personnel to clean the internal part of the TV once a year.



Do not cover or block any vents and openings. Inadequate ventilation may shorten the life of the display unit and cause overheating.



Do not place the display near water, such as bathtub, washbasin, kitchen sink laundry tub, swimming pool or in a damp basement.



Notice for Remote Controller

Avoid Dropping



Avoid Liquids



Avoid Aerosol Cleaners



IMPORTANT SAFETY INSTRUCTIONS


Read before operating equipment

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.
7. Do not block any of the ventilation openings. Install in accordance with the manufacturers instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and third grounding prong. The wide blade or third prong is provided for your safety. When the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with a cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.



13. The TV should be operated only from the type of power source indicated on the label. If you are not sure of the type of power supplied to your home, consult your dealer or local power company.
14. Unplug this apparatus during lightning storms or when unused for long periods of time.
15. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
16. This product may contain lead or mercury. Disposal of these materials may be regulated due to environmental considerations. For disposal or recycling information, please contact your local authorities or the Electronic Industries Alliance: www.eiae.org
17. **Damage Requiring Service** – The appliance should be serviced by qualified service personnel when:
 - A. The power supply cord or the plug has been damaged; or
 - B. Objects have fallen, or liquid has been spilled into the appliance; or
 - C. The appliance has been exposed to rain; or

- D. The appliance does not appear to operate normally or exhibits a marked change in performance; or
- E. The appliance has been dropped, or the enclosure damaged.
18. **Tilt/Stability** – All televisions must comply with recommended international global safety standards for tilt and stability properties of its cabinets design.
- Do not compromise these design standards by applying excessive pull force to the front, or top, of the cabinet, which could ultimately overturn the product.
 - Also, do not endanger yourself, or children, by placing electronic equipment/toys on the top of the cabinet. Such items could unsuspectingly fall from the top of the set and cause product damage and/or personal injury.
19. **Wall or Ceiling Mounting** – The appliance should be mounted to a wall or ceiling only as recommended by the manufacturer.
20. **Power Lines** – An outdoor antenna should be located away from power lines.
21. **Outdoor Antenna Grounding** – If an outside antenna is connected to the receiver, be sure the antenna system is grounded so as to provide some protection against voltage surges and built up static charges. Section 810 of the National Electric Code, ANSI/NFPA No. 70-1984, provides information with respect to proper grounding of the mast and supporting structure grounding of the lead-in wire to an antenna-discharge unit, size of grounding connectors, location of antenna-discharge unit, connection to grounding electrodes and requirements for the grounding electrode. See Figure below.



EXAMPLE OF ANTENNA GROUNDING AS PER NATIONAL ELECTRICAL CODE

Note to the CATV system installer: This reminder is provided to call the CATV system installer's attention to Article 820-40 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.


Please, make sure to connect the power plug to the wall outlet socket after connecting the TV to the adapter!

22. **Objects and Liquid Entry** – Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through openings.

PREPARATION

Please, make sure to connect the power plug to the wall outlet socket after connecting the TV to the power cord!

1. **Install the base stand; place the TV on a solid surface.**




Ensure that the TV is placed in a position to allow free flow of air. Do not cover the ventilation openings on the back cover.

To prevent any unsafe situations, no naked flame sources, such as lighted candles, should be placed on or in the vicinity.


Avoid heat, direct sunlight and exposure to rain or water. The equipment shall not be exposed to dripping or splashing.

2. Connect the antenna cable or CATV cable to the aerial socket **ANT IN 75Ω** at the back of the TV set.



3. **Remote control:**

Remove the cover of the battery compartment. Insert the 2 batteries supplied (Type AAA 1.5V).




4. **Power:**


Insert the power cord in the wall socket having an AC power supply. You can see LED states at the front panel. If the LED color is Blue, means the TV set is power on. If the LED color is Red, which means this TV set is in standby state.

5. **Turn the TV on:**

Push the POWER key on the Remote control or the Front panel control knobs. Wait a minute, the TV will power on and can see the display on the screen



PERIPHERAL CONNECTION GUIDE




Once your equipment is connected, use the following procedure to view the input signal:

Press the Source button or direct input buttons on the remote controller to select the relevant source to view. (ex: Press Video button to select "Composite" if you have connected a video recorder to Composite socket.)

Note: For W2613, only HDMI 1 is available.

OPERATION INSTRUCTIONS

TO USE THE FRONT PANEL CONTROL



1.	VOL +	VOL +: Press to increase the sound volume level.
2.	VOL -	VOL - : Press to decrease the sound volume level.
3.	CH ▲	CH +: Press to select the next higher Program number.
4.	CH ▼	CH - : Press to select the next lower Program number.
5.	MENU	Menu key: Press to open or exit the OSD menu.
6.	INPUT	Source key: Press to select the input source.
7.	POWER	Power key: Press to turn on / off (standby) the TV set. (Please re-turn on TV after the Power-ON status LED had changed to the Red color and finished flashing.)

TO USE THE REMOTE CONTROL

Power:

Press to power ON/OFF (standby) TV.

Note:

1. TV is never completely power off unless physically unplugged.
2. Press Power Key to turn on TV after the power status LED had changed to red color and stopped flashing.

Video:

Press repeatedly to choose S-Video/Composite source mode

Comp:

Press repeatedly to choose Component source mode

PC/HDMI:

Press repeatedly to choose VGA or HDMI source mode.

TV:

Press to choose TV source mode.

0~9/- number:

Press to enter TV channel number to select channel (press '-' to indicate of choosing the sub-channel).

Sleep:

Press to set sleep timer (off/5 min/10 min/15 min/30 min/45 min/60 min/90 min/120 min/180 min/240 min) for TV to switch to standby mode automatically.

Freeze:

Press to freeze the displayed picture

CH+/CH-:


Press + or - to browse through the TV channels.

Menu:

Press to open or exit menu.

Direction keys and ENTER:

Press to adjust the various function items on the menu.



PREV CH:

Press to display the previous TV channel.

MTS/SAP:

Press to activate the NTSC TV sounds, such as: Stereo, SAP or Mono tone, and languages of DTV.

Zoom:

Press to choose the display aspect as: Standard, Fill and Overscan mode.

Source:

Press repeatedly to choose the various input sources.

EPG:

This function is not support.

Mute:

Press to set TVsound mute ON/OFF

Info:

Press to show the information about the input source, TV channel, display resolution.

VOL- / VOL+:

Press + or - to adjust the volume.

Exit:

Press to exit menu or OSD.

V-Chip:

Press to lock / unlock Parental Control temporarily. (After setting the restricted table of MPAA or TV Rating.)

Video Adj:

Press to choose the Brightness or Contrast adjustment.

Audio Adj:

Press to switch the ATSC multi-channel TV sounds.

C. C.:

Press repeatedly to change the closed caption type as CC ON/CC OFF/CC ON WHEN MUTE.


TO USE THE MENUS

1. Press the **Menu** button to display the main menu
2. Use the **cursor Up/Down** to select a menu item.
3. Use the **cursor Left/Right** to enter a submenu.
4. Press the **ENTER** button to enable/disable the function.
5. Press the **Menu** or **Exit** button to exit the menu.

Press the Menu button to enter the main OSD (On Screen Display). Adjust the items including **Setup menu**, **Video menu**, **Audio menu** and **Feature menu**. However, some function items in the menus may only be enabled in the particular source modes.

SETUP MENU

The Setup menu in TV mode shows as below. In others source modes, the Setup menu only shows **Menu Language** and **Aspect Ratio** items.



1. **Tuning Band:** Select TV source signal from the Air (antenna) or Cable (CATV).
2. **DTV Signal:** Show the intensity of the received DTV signal.




3. **Auto Ch Search:** Automatically scan all NTSC / ATSC TV channels and then store in the channel table. In channel scan process, the OSD can display the number of channels which had been found.
4. **Add on Ch search:** Add channels which are new found.
5. **Manual Channel Set:** Show the channel setup table. User can choose to display the ATSC or NTSC TV channels and then edit the channel (Viewable or Not Viewable by pressing Enter button). User won't be able to view the

channel that has been set to Not Viewable when toggling through channels. However, the channels are still accessible when user enters the channel number.

6. **Channel Labels:** Show the NTSC / ATSC TV channel label menu for user modifying channel labels specifically.
7. **Menu Language:** Select the menu display language. (English / Espanol / Francais)
8. **Aspect Ratio:** Select the display aspect ratio. (Standard/Fill/Overscan)
9. **Favorite Channel Mode:** When favorite channel mode is on, user can edit favorite channel table in favorite channel set option.

VIDEO MENU


The Video menu in most source modes shows as below. It provides several video adjustment items for user fine tuning the video display. Only in VGA source modes, the Video menu simply provides **Contrast**, **Brightness**, **Back light** and **Settings (Preset)** items.



1. **Contrast:** Video contrast adjustment, the tuning range is 0 ~ 100.
2. **Brightness:** Video brightness adjustment, the tuning range is 0 ~ 100.
3. **Sharpness:** Video sharpness adjustment, the tuning range is -50 ~ 50.
4. **Color:** Video color chroma adjustment, the tuning range is 0 ~ 100.
5. **Tint:** Video tint adjustment, the tuning range is R50 ~ G50.
6. **BackLight:** Backlight strength adjustment, the tuning range is 0 ~ 10.
7. **Settings:** Restore the default video settings.

AUDIO MENU


The Audio menu in TV mode shows as below. It provides audio adjustment for user to modify the audio setting. Audio language setting is only available with ATSC TV source, the option is disable under other source modes.




1. **Audio Language:** Change the audio language setting on ATSC TV programs. The number of the supported audio languages depends on the ATSC TV programs.
2. **Bass:** Bass tone adjustment, the tuning range is 0 ~ 63. (The default state is enabled)
3. **Treble:** Treble tone adjustment, the tuning range is 0 ~ 63. (The default state is enabled)
4. **Balance:** Audio balance adjustment, the tuning range is L31 ~ R31.)
5. **Digital Audio Output:** Digital audio output format selection, user can choose RAW (default) or PCM format or off.
6. **TV Speaker:** Choose to turn on / off the TV internal speaker. The digital audio output signals · earphone output signals will not be turn-off even though the TV speaker is off. The default setting is On.
7. **Settings:** Restore the default audio settings.

FEATURE MENU

The Feature menu in TV mode shows as below. It provides certain optional control functions such as time set, sleep timer, advanced video menu, Password Set, parental control (V-chip) and Digital closed caption setting. This menu gives users the most flexibilities to satisfy their generally demands. According to the various requirements in different source modes, certain features should be hidden (disable) on the menu. The details footnotes will be described clearly below.



1. **Time Set:** Set current time. This sub-menu includes Time Set Mode, Time Zone and Time items. 【Time Set Mode】 user can choose Auto or Manual, 【Time Zone】 item provides user to set current time zone, such as: Pacific, Alaska, Hawaii, Eastern, Central and Mountain. 【Time】 item provides user to set the time clock.



2. **Sleep Timer:** Enable or disable the TV standby timer. User can set the TV standby timer as off / 5 min / 10 min / 15 min / 30 min / 45 min / 60 min / 90 min / 120 min / 180min / 240min. Timer starts to count down after cursor leaving the sub-menu. (At the moment, the item shows 『** min Left』 and the cursor highlights on the Feature icon.)

3. **Advanced Video Menu:** Provide the Noise Reduction · Color Temperature and 3D Y/C. Dynamic Contrast options for enhancing video quality.
【Noise Reduction】 gives four NR effect degrees, such as: Low, Mid, High and Off. The default setting is Mid.
【Colour Temp】 gives three color temperature modes as: Normal · Warm and Cool.
【3D Y/C】 provides On / Off switches. The default setting is On.
【Dynamic Contrast】 user can choose On or Off.
【Setting】 restores the default advanced video option settings.

4. **Password Set:** Change the 4-numeral parental control password. Three steps are required for changing the password: Enter Old Password -> Enter New Password -> Confirm New Password. Note: This item is only available in TV, Composite and S-Video source modes. The default password is 『0 0 0 0』.



Enter Old Password
□ □ □ □

Enter New Password
□ □ □ □


Confirm New Password
□ □ □ □

5. **Parental Control:** provide the parental Control (V-chip) function setting. Before entering the Parental Control sub-menu, user has to key in the password first. Then enter the Parental Lock item, User can modify the restricted table about MPAA or TV Rating respectively. While exiting the sub-menu, the parental control function is working. The inhibitive channels or source signals can be un-lock through pressing the V-CHIP key on the remote control and then key in the correct password. Note: This feature is only available in TV, Composite and S-Video source modes. (The default password is: 0 0 0 0.)

Enter Password
□ □ □ □



6. **Digital Captions:** Select the close caption options (Service 1-6, Text 1-4 and CC 1-4) in digital TV mode. When select service 1 to service 6 you can modulate parameters in the Digital Close Caption.
7. **Digital Close Caption:** Provide numerous options for setting the digital close caption style. In the sub-menu.
 - 【Style】 item can be set as Automatic or Custom mode. If Custom mode is selected, user can modify the detail styles described below. The setting result will be shown immediately on the bottom side of the sub-menu OSD. Note: This feature is only available in Digital TV(ATSC) mode.



- 【Size】 : Digital close caption font size, which can be set as Small · Normal or Large.
- 【Font】 : Digital close caption font style, which can be chosen as Default or Font 1 ~ 7.
- 【Text Color】 : Giving Red / Green / Blue/ Yellow / Magenta / Cyan / Black / White Colors.

【Text Opacity】 : Giving Transparent / Translucent / Solid / Flashing modes.







【Background Color】 : Giving Red / Green / Blue / Yellow / Magenta / Cyan / Black / White Colors.

【Background Opacity】 : Giving Transparent / Translucent / Solid / Flashing modes.







【Edge Effect】 : The text edge effects, which gives None / Raised / Depressed / Uniform / Left Shadow / Right Shadow modes.

【Edge Color】 : The colors of text edge effects, which provides Red / Green / Blue / Yellow / Magenta / Cyan / Black / White Colors.

8. **Component Set:** This option only shows and is available in component mode, which provides fine tuning component display, such as: 【H-Position】、【V-Position】、【Clock】 and 【Phase】 (Auto Adjust function is not supported under Component mode). All these items are giving the tuning range from 0 to 100. 【Setting】 item provides the default component setting values restoring.

Component setting-720x480i@30/29.97Hz	
H-Position	50 
V-Position	50 
Clock	50 
Phase	50 
Auto Adjust	
Setting	
⏏ To Move Enter To Select Exit To Exit	

9. **VGA Set:** This option only shows and is available in VGA mode, which provides several items for the VGA display fine tuning, such as : 【H-Position】、【V-Position】、【Clock】、【Phase】、 and 【Auto Adjust】 . All these items giving the tuning range from 0 to 100. 【Setting】 item provides the default VGA setting values restoring.

VGA setting - 1360x768x60	
H-Position	50 
V-Position	50 
Clock	50 
Phase	50 
Auto adjust	
Setting	
⏏ To Move Enter To Select Exit To Exit	

TIPS

Care of the screen

Do not rub or strike the screen with anything hard as this may scratch, mar, or damage the screen permanently.

Unplug the power cord before cleaning the screen. Dust the TV by wiping the screen and the cabinet with a soft, clean cloth. If the screen requires additional cleaning, use a clean, damp cloth. Do not use liquid cleaners or aerosol cleaners.

Mobile telephone warning

To avoid disturbances in picture and sound, malfunctioning of your TV or even damage to the TV, keep away your mobile telephone from the TV.

End of life directives

We are paying a lot of attention to produce environmentally friendly in green focal areas. Your new receiver contains materials, which can be recycled and reused.

At the end of its life specialized companies can dismantle the discarded receiver to concentrate the reusable materials and to minimize the amount of materials to be disposed of.

Please ensure you dispose of your old receiver according to local regulations.

Regulatory Notices – Federal Communications Commission Notice

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the TV.
- Connect the equipment into wall power outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio or television technician for help.

Modifications –

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by Westinghouse Digital Electronics, LLC. may void the user's authority to operate the equipment.

Cables –

Connections to this device must be made with shielded cables with metallic RF/EMI connector hoods to maintain compliance with FCC Rules and Regulations.

Canadian notice –

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Avis Canadian –

Cat appareil numerous de la classed B respected toutes les exigences du règlement sur le materiel brouilleur du Canada.

Dolby –



Manufactured under license from Dolby Laboratories. Dolby and the double-D symble are registered trademarks of Dolby Laboratories.

HDMI –

HDMI, the HDMI logo, and High-Definition Multimedia Interface are trademarks of registered trademarks of HDMI Licensing LLC.

PRODUCT SPECIFICATION

NOTE:

- This model complies with the specifications listed below.
- Designs and specifications are subject to change without notice.
- This model may not be compatible with features and/or specifications that may be added in the future.
- 32" LCD TV (31.5" viewable) Viewable image size: diagonal 800 mm

<p>Television System: NTSC standard ATSC standard (8-VSB, Clear-QAM)</p>	<p>HDMI Terminals: HDMI INPUT: Rear HDMI x2 HDCP compliant E-EDID compliant Supported scan rates: 1080i, 720p, 480p, 480i</p>
<p>Channel Coverage: VHF: 2 through 13 UHF: 14 through 69 Cable TV: Mild band (A-8 through A-1, A through I) Super band (J through W) Hyper band (AA through ZZ, AAA, BBB) Ultra band (65 through 94, 100 through 125)</p>	<p>VGA Terminals: VGA INPUT: Rear VGA (D-SUB 15 Pin) Input x1 E-EDID compliant Supported scan rates: 640X480 /60Hz/72Hz/75Hz 720X400 /70Hz 800x600 /56Hz /60Hz /72Hz /75Hz 1024X768 /60Hz/70Hz/75Hz 1360X768 /60Hz 1366X768 /60Hz Recommended: 1366X768 /60Hz Audio INPUT: Headphone Mini-jack for stereo (3.5Φ)</p>
<p>Power Source: AC power supply: 100V~240 V, 50/60 Hz</p>	
<p>Power Consumption: ≤ 180 W 1 W in standby mode (power cord plugged in and power OFF)</p>	<p>Dimensions: Include Stand: 782.5mm(W) x 558.6mm(H) x 209.0mm(L)</p>
<p>Audio Power: 5 W + 5 W, Internal Speaker</p>	<p>Weight: 11.3 kg(With Stand)</p>
<p>Video/Audio Terminals: Rear AV x1: S-Video/Video/Audio Input</p>	<p>Wall Mounting: 200x200mm (Wall mount kit is not included)</p>
<p>S-VIDEO INPUT: Y : 1 V(p-p), 75 ohm, negative sync. C : 0.286 V(p-p) (burst signal), 75 ohm</p> <p>VIDEO/AUDIO INPUT: VIDEO: 1 V(p-p), 75 ohm, negative sync. AUDIO: 0.5V(rms)</p>	<p>Supplied Accessories: 1pcs Power cord 1pcs Remote control (with two size AAA alkaline batteries) 1pcs User manual</p>
<p>Component INPUT: Rear Component x1: Y : 1V(p-p), 75 ohm, including sync. Pr/Cr: ±0.35V(p-p), 75 ohm Pb/Cb: ±0.35V(p-p), 75 ohm AUDIO: 0.5V(rms) Supported resolutions: 1080i, 720p, 480p, 480i</p>	

PRODUCT SPECIFICATION

*26" LCD TV (26" viewable) Viewable image size: diagonal 660 mm

Television System: NTSC standard ATSC standard (8-VSB, Clear-QAM)	HDMI Terminals: HDMI INPUT: Rear HDMI x1 HDCP compliant E-EDID compliant Supported scan rates: 1080i, 720p, 480p, 480i
Channel Coverage: VHF: 2 through 13 UHF: 14 through 69 Cable TV: Mild band (A-8 through A-1, A through I) Super band (J through W) Hyper band (AA through ZZ, AAA, BBB) Ultra band (65 through 94, 100 through 125)	VGA Terminals: VGA INPUT: Rear VGA (D-SUB 15 Pin) Input x1 E-EDID compliant Supported scan rates: 640X480 /60Hz/72Hz/75Hz 720X400 /70Hz 800x600 /56Hz /60Hz /72Hz /75Hz 1024X768 /60Hz/70Hz/75Hz 1360X768 /60Hz 1366X768 /60Hz Recommended: 1366X768 /60Hz Audio INPUT: Headphone Mini-jack for stereo (3.5Φ)
Power Source: AC power supply: 100V~240 V, 50/60 Hz	
Power Consumption: ≤ 120 W 1 W in standby mode (power cord plugged in and power OFF)	Dimensions: Include Stand: 651.9mm(W) x 481.0mm(H) x 219.7mm(L)
Audio Power: 5 W + 5 W, Internal Speaker	Weight: 9.0 kg(With Stand)
Video/Audio Terminals: Rear AV x1: S-Video/Video/Audio Input	Wall Mounting: 200x100mm (Wall mount kit is not included)
S-VIDEO INPUT: Y : 1 V(p-p), 75 ohm, negative sync. C : 0.286 V(p-p) (burst signal), 75 ohm VIDEO/AUDIO INPUT: VIDEO: 1 V(p-p), 75 ohm, negative sync. AUDIO: 0.5V(rms)	Supplied Accessories: 1pcs Power cord 1pcs Remote control (with two size AAA alkaline batteries) 1pcs User manual
Component INPUT: Rear Component x1: Y : 1V(p-p), 75 ohm, including sync. Pr/Cr: ±0.35V(p-p), 75 ohm Pb/Cb: ±0.35V(p-p), 75 ohm AUDIO: 0.5V(rms) Supported resolutions: 1080i, 720p, 480p, 480i	

BEFORE CALLING SERVICE

Please make these simple checks before calling service. These tips may save you time and money since charges for receiver installation and adjustments of customer controls are not covered under your warranty.

Symptoms	Items to Check and Actions to follow
"Ghost " or double image	*This may be caused by obstruction to the antenna due to high rise buildings or hills. Using a highly directional antenna may improve the picture.
No power	*Check that the TV's AC power cord is plugged into the mains socket. *Unplug the TV, wait for 60 seconds. Then re-insert plug into the mains socket and turn on the TV again.
No picture	*Check antenna connections at the rear of the TV to see if it is properly connected to the TV. *Possible broadcast station trouble. Try another channel. *Adjust the contrast and brightness settings. *Check the Closed Captions control. Some TEXT modes could block the screen,
Good picture but no sound	*Increase the VOLUME. *Check that the TV is not muted; press the MUTE button on the remote control.
Good sound but poor color	*Adjust the contrast, color and brightness settings.
Poor picture	*Sometimes, poor picture quality occurs when having activated an S-VHS camera or camcorder connected and having connected another peripheral at the same time. In this case switch off one of the other peripherals
Snowy picture and noise	*Check the antenna connection
Horizontal dotted line	*This may be caused by electrical interference (e.g. hairdryer, nearby neon lights, etc.) *Turn off the equipment.
Television not responding to remote control	*Check whether the batteries are working. Replace if necessary *Clean the remote control sensor lens on the TV. *You can still use the buttons at the front of your TV. *Select the TV mode to be sure your remote control is in the TV mode.

GLOSSARY

Audio / Video Inputs

Located on the rear of the set. These connectors (RCA phono type plug) are used for the input of audio and video signals. Designed for use with VCRs (or other source equipments) in order to receive higher picture resolution and offer sound connection options.

Menu

An on-screen listing of features shown on the TV screen is made available for user adjustments.

MPAA

Motion Picture Association of America

Multichannel Television sound (MTS)

The broadcasting standard, which allows stereo sounds to be transmitted with the TV picture.

RF

Radio Frequency or modulated signal design used as the carrier for television broadcasts.

Second Audio Program (SAP)

Another or additional audio channel provided for in the Multichannel Television Sound (MTS) broadcast standard. A monaural soundtrack included within the recorded or video signal (usually containing a second language translation for the displayed program).

Sleep Timer

You can set a time period for which the TV will automatically turn itself off.

S-Video Input


You can connect your TV set to a high-resolution video source (such as Super VHS video-cassette recorder, Laser Disc player and DVD Home Theater Set) in order to provide maximum consumer viewing satisfaction.

APPENDIX:

MOUNTING THE TV BASE


The TV base will be separated with the TV unit. You should install the base before you use the TV unit.

1. Place the TV on its face on a soft blanket.
2. Install the base stand with screws (4 screws for 32"; 3 screws for 26").
3. Place the TV on the table.



REMOVE TABLE STAND FOR WALL MOUNTING

You have to release 4 screws (3 screws for 26") to remove table stand for wall mounting.



This apparatus is intended to be supported by UL Listed Wall Mount Bracket.