

**42MF438B**  
**47MF438B**  
**52MF438B**

 Thank you for choosing Magnavox.

**Need help fast?**

Read your Quick Use Guide and/or Owner's Manual first for quick tips that make using your Magnavox product more enjoyable.

If you have read your instructions and still need assistance, you may access our online help at [www.magnavox.com/usasupport](http://www.magnavox.com/usasupport) or call **1-800-705-2000** while with your product (and Model / Serial number)

 Magnavox vous remercie de votre confiance.

**Besoin d'une aide rapide?**

Les Guide d'utilisation rapide et Manuel de l'utilisateur regorgent d'astuces destinées à simplifier l'utilisation de votre produit Magnavox.

Toutefois, si vous ne parvenez pas à résoudre votre problème, vous pouvez accéder à notre aide en ligne à l'adresse [www.magnavox.com/usasupport](http://www.magnavox.com/usasupport) ou formez le **1-800-705-2000**

Veillez à avoir votre produit à portée de main (et model / serial nombre)

 Gracias por escoger Magnavox.

**Necesita ayuda inmediata?**

Lea primero la Guía de uso rápido o el Manual del usuario, en donde encontrará consejos que le ayudarán a disfrutar plenamente de su producto Magnavox.

Si después de leerlo aún necesita ayuda, consulte nuestro servicio de asistencia en línea en [www.magnavox.com/usasupport](http://www.magnavox.com/usasupport) o llame al teléfono **1-800-705-2000** y tenga a mano el producto (y número de model / serial)

For Customer Use / À l'usage du client /  
Para Uso del Cliente

Model/Modle/Modelo No. : \_\_\_\_\_

Serial/Srie/Serie No. : \_\_\_\_\_



**Return your Product Registration Card or register online at [www.magnavox.com/usasupport](http://www.magnavox.com/usasupport) today to get the very most from your purchase**

Registering your model with MAGNAVOX makes you eligible for all of the valuable benefits listed below, so don't miss out. Complete and return your Product Registration Card at once, or register online at [www.magnavox.com/usasupport](http://www.magnavox.com/usasupport) to ensure:

**\*Proof of Purchase**  
Returning the enclosed card guarantees that your date of purchase will be on file, so no additional paperwork will be required from you to obtain warranty service.

**\*Product Safety Notification**  
By registering your product, you'll receive notification - directly from the manufacturer - in the rare case of a product recall or safety defect.

**\*Additional Benefits**  
Registering your product guarantees that you'll receive all of the privileges to which you're entitled, including a special money-saving offers.

# MAGNAVOX

**Congratulations on your purchase, and welcome to the "family!"**

**Dear MAGNAVOX product owner:**  
Thank you for your confidence in MAGNAVOX. You've selected one of the best-built, best-backed products available today. We'll do everything in our power to keep you happy with your purchase for many years to come.

As a member of the MAGNAVOX "family," you're entitled to protection by one of the most comprehensive warranties and outstanding service networks in the industry. What's more, your purchase guarantees you'll receive all the information and special offers for which you qualify, plus easy access to accessories from our convenient home shopping network.


Most importantly, you can count on our uncompromising commitment to your total satisfaction.


All of this is our way of saying welcome - and thanks for investing in a MAGNAVOX product.

**P.S. To get the most from your MAGNAVOX purchase, be sure to complete and return your Product Registration Card at once or register online at: [www.magnavox.com/usasupport](http://www.magnavox.com/usasupport)**

Know these **safety symbols**



 This "bolt of lightning" indicates uninsulated material within your unit may cause an electrical shock. For the safety of everyone in your household, please do not remove product covering.

 The "exclamation point" calls attention to features for which you should read the enclosed literature closely to prevent operating and maintenance problems.

**WARNING:** To reduce the risk of fire or electric shock, this apparatus should not be exposed to rain or moisture and objects filled with liquids, such as vases, should not be placed on this apparatus.

**CAUTION:** To prevent electric shock, match wide blade of plug to wide slot, fully insert.

**ATTENTION:** Pour éviter les choc électriques, introduire la lame la plus large de la fiche dans la borne correspondante de la prise et pousser jusqu'au fond.


**For Customer Use**


Enter below the Serial No. which is located on the rear of the cabinet. Retain this information for future reference.

Model No. \_\_\_\_\_  
Serial No. \_\_\_\_\_

## IMPORTANT SAFETY INSTRUCTIONS

### Read before operating equipment

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.
7. Do not block any of the ventilation openings. Install in accordance with the manufacturers instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and third grounding prong. The wide blade or third prong are provided for your safety. When the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12.  Use only with a cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
13. Unplug this apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. This product may contain lead or mercury. Disposal of these materials may be regulated due to environmental considerations. For disposal or recycling information, please contact your local authorities or the Electronic Industries Alliance: www.eiae.org.
16. **Damage Requiring Service** - The appliance should be serviced by qualified service personnel when:
  - A. The power supply cord or the plug has been damaged; or
  - B. Objects have fallen, or liquid has been spilled into the appliance; or
  - C. The appliance has been exposed to rain; or
  - D. The appliance does not appear to operate normally or exhibits a marked change in performance; or
  - E. The appliance has been dropped, or the enclosure damaged.
17. **Tilt/Stability** - All televisions must comply with recommended international global safety standards for tilt and stability properties of its cabinets design.
  - Do not compromise these design standards by applying excessive pull force to the front, or top, of the cabinet which could ultimately overturn the product.
  - Also, do not endanger yourself, or children, by placing electronic equipment/toys on the top of the cabinet. Such items could unsuspectingly fall from the top of the set and cause product damage and/or personal injury.
18. **Wall or Ceiling Mounting** - The appliance should be mounted to a wall or ceiling only as recommended by the manufacturer.
19. **Power Lines** - An outdoor antenna should be located away from power lines.
20. **Outdoor Antenna Grounding** - If an outside antenna is connected to the receiver, be sure the antenna system is grounded so as to provide some protection against voltage surges and built up static charges. Section 810 of the National Electric Code, ANSI/NFPA No. 70-1984, provides information with respect to proper grounding of the mats and supporting structure grounding of the lead-in wire to an antenna-discharge unit, size of grounding connectors, location of antenna-discharge unit, connection to grounding electrodes and requirements for the grounding electrode. See Figure below.
21. **Objects and Liquid Entry** - Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through openings.
  - a) **Warning:** To reduce the risk of fire or electric shock, this apparatus should not be exposed to rain or moisture and objects filled with liquids, such as vases should not be placed on this apparatus.
22. **Battery Usage CAUTION** - To prevent battery leakage that may result in bodily injury, property damage, or damage to the unit:
  - Install all batteries correctly, with + and - alignment as marked on the unit.
  - Do not mix batteries (old and new or carbon and alkaline, etc.)
  - Remove batteries when the unit is not used for a long time.



**Note to the CATV system installer:** this reminder is provided to call the CATV system installer's attention to Article 820-40 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building, as close to the point of cable entry as practical.

Specifications are subject to change without notice. Trademarks are the property of their respective owners.

© 2008 Magnavox. All rights reserved.

Magnavox reserves the right to change products at any time without being obliged to adjust earlier supplies accordingly.

The material in this manual is believed adequate for the intended use of the system. If the product, or its individual modules or procedures, are used for purposes other than those specified herein, confirmation of their validity and suitability must be obtained. Magnavox warrants that the material itself does not infringe any United States patents. No further warranty is expressed or implied.

Magnavox can't be held responsible neither for any errors in the content of this document nor for any problems as a result of the content in this document. Errors reported to Magnavox will be adapted and published on the Magnavox support website as soon as possible.

#### Warranty

No components are user-serviceable. Do not open or remove covers to the inside of the product. Repairs may only be done by Magnavox Service Centers and official repair shops. Failure to do so shall void any warranty, stated or implied. Any operation expressly prohibited in this manual, any adjustments, or assembly procedures not recommended or authorized in this manual shall void the warranty.

#### Pixel characteristics

This LCD product has a high number of color pixels. Although it has effective pixels of 99,999% or more, black dots or bright points of light (red, green or blue) may appear constantly on the screen. This is a structural property of the display (within common industry standards) and is not a malfunction.

#### Federal Communications Commission Notice

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio or television technician for help.

#### Modifications

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by Magnavox may void the user's authority to operate the equipment.

#### Cables

Connections to this device must be made with shielded cables with metallic RFI/EMI connector hoods to maintain compliance with FCC Rules and Regulations.

#### Canadian notice

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

#### Avis Canadien

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

#### Copyright



VESA, FDMI and the VESA Mounting Compliant logo are trademarks of the Video Electronics Standards Association.



Manufactured under license from Dolby Laboratories. 'Dolby' and the double D symbol are trademarks of Dolby Laboratories.



Manufactured under license from BBE Sound, Inc. Licensed by BBE, Inc under one or more of the following US patents: 5510752, 5736897. BBE and BBE symbol are registered trademarks of BBE Sound Inc.

© Kensington and Micro Saver are registered US trademarks of ACCO World Corporation with issued registrations and pending applications in other countries throughout the world. All other registered and unregistered trademarks are the property of their respective owners.

Portions of this software are copyright © The FreeType Project ([www.freetype.org](http://www.freetype.org)).

## Contents

<b>1. Important</b> . . . . .	<b>5</b>	<b>6. Change your TV installation</b> . . . . .	<b>23</b>
Product information . . . . .	5	Select your menu language . . . . .	23
Screen care . . . . .	5	Set your location to home . . . . .	23
Environmental care . . . . .	5	Tune channels automatically . . . . .	23
Regulatory notices . . . . .	5	Optimize the signal quality from your antenna . . . . .	23
		Uninstall and reinstall channels . . . . .	24
		Return your settings to default values . . . . .	24
		Show emergency alerts (EAS) . . . . .	24
<b>2. Your TV</b> . . . . .	<b>6</b>		
Television overview . . . . .	6	<b>7. Update your TV software</b> . . . . .	<b>25</b>
Remote control . . . . .	6	Check your current software version . . . . .	25
		Prepare for the software upgrade . . . . .	25
		Upgrade software . . . . .	25
<b>3. Get started</b> . . . . .	<b>7</b>		
Position the TV . . . . .	7	<b>8. Connect devices</b> . . . . .	<b>26</b>
Install the remote control batteries . . . . .	7	Connection overview . . . . .	26
Connect the antenna or cable . . . . .	7	Select your connection quality . . . . .	27
Connect the power cord . . . . .	8	Label your connections . . . . .	27
Manage cables . . . . .	8	Connect your devices . . . . .	28
Switch on and setup the TV . . . . .	9		
<b>4. Use your TV</b> . . . . .	<b>10</b>	<b>9. Glossary</b> . . . . .	<b>31</b>
Switch your TV on/off or to standby . . . . .	10		
Watch TV . . . . .	10	<b>10. Troubleshooting</b> . . . . .	<b>32</b>
Watch channels from a set-top box . . . . .	11		
Watch connected devices . . . . .	11	<b>11. Notes for the use of USB devices</b> . . . . .	<b>33</b>
Watch a DVD . . . . .	11		
<b>5. Use more of your TV</b> . . . . .	<b>12</b>	<b>12. Technical specifications</b> . . . . .	<b>34</b>
Understand the remote control . . . . .	12		
Use the quick access menu . . . . .	13	<b>13. Index</b> . . . . .	<b>35</b>
Change picture and sound settings . . . . .	13		
Use Smart Mode . . . . .	15	<b>14. Warranty</b> . . . . .	<b>37</b>
Create and use lists of favorite channels . . . . .	15		
Set the clock . . . . .	16		
Set the sleeptimer . . . . .	16		
Use child control and rating locks . . . . .	17		
View closed captions (subtitles) . . . . .	20		
Use your TV in HDTV mode . . . . .	21		
Use your TV as a PC monitor . . . . .	22		

## 1. Important


### 1.1 Product information

The model and serial number are on the rear of the TV and on the packaging.

This TV consumes minimal energy in standby mode to minimize environmental impact. The active power consumption is given on the type plate at the rear of the TV.

### 1.2 Screen care

- Turn off and unplug the power cord before cleaning the screen.
- Clean the screen with a soft, dry cloth. Do not use substances such as household cleaning agents as these may damage the screen.



- To avoid deformations or color fading, wipe off water droplets as soon as possible.
- Do not touch, push, rub or strike the screen with hard objects as this may damage the screen permanently.
- Where possible, avoid stationary images that remain on-screen for extended periods of time. If you must use stationary images, reduce the screen contrast and brightness to avoid screen damage.

### 1.3 Environmental care



#### Recycling

The packaging of this product is intended to be recycled. Contact your local authorities for information about how to recycle the packaging.



#### End of life directives

Like all LCD products, this set contains a lamp with Mercury, please dispose of according to all Local, State and Federal laws.

Magnavox is paying a lot of attention to produce environmentally-friendly products in green focal areas. Your new TV contains materials which can be recycled and reused. At the end of its life, specialized companies can dismantle the discarded TV to concentrate the reusable materials and to minimize the amount of materials to be disposed off. Please ensure you dispose off your old TV according to local regulations.

#### Disposal of batteries

The batteries supplied do not contain the heavy metals mercury and cadmium. Nevertheless, in many areas batteries may not be disposed of with your household waste. Please ensure you dispose of batteries according to local regulations.

### 1.4 Regulatory notices

**⚠ WARNING:** To reduce the risk of fire or electric shock, this apparatus should not be exposed to rain or moisture. Objects filled with liquids, such as vases, should not be placed on this apparatus.


**⚠ CAUTION:** To prevent electric shock, match the wide blade of the plug to the wide slot, fully insert.

## 2. Your TV

This section describes the controls and functions of your TV.


### 2.1 Television overview

#### Front and side controls




1. Power switch
2. Channel up/down
3. Menu  
(The **MENU** key can be used as an **OK** key in some sub menus.)
4. Volume up/down
5. Remote control sensor

#### Side connectors



Use the TV side connectors to connect to mobile devices such as a high definition game console. You can also connect a pair of headphones.


#### Back connectors



Use the TV back connectors to connect to the antenna or cable, and to permanent devices such as a high definition disc player, DVD player, or VCR.

For more information about TV connections, see *Connect your devices* on page 28.

### 2.2 Remote control



1. Standby / ON
2. Source selection
3. Color buttons
4. Cursor buttons
5. OK button
6. Menu button
7. Channel selection
8. Volume

For more information about the remote control, see *Understand the remote control* on page 12.



## 3. Get started

This section describes how to position and connect your TV, and how to perform your first-time installation.

### 3.1 Position the TV

#### ⚠ Warning

- Do not insert the power plug into the wall socket before all the connections are made.
- Large screen TVs are heavy. Two people are required to carry and handle the TV.
- Before you move your TV, disconnect the cables to prevent breakage.

Wherever you decide to position your TV, ensure that you always have easy access to the power cord or plug to disconnect the TV from the power.

If the TV is mounted on a stand, ensure no strain is placed on the power cord when turning the TV. Strain on the power cord can loosen connections.


For ideal viewing conditions, position the TV where light does not fall directly on the screen.

The ideal viewing distance for watching TV is three times its screen size.


#### Kensington security slot

Your TV is equipped with a Kensington Security Slot at the back of the TV.

If you connect an anti-theft Kensington lock (not supplied), position the TV within reach of a permanent object that can be attached to the lock.



### 3.2 Install the remote control batteries



1. Open the battery cover on the back of the remote control.
2. Insert the 2 batteries supplied. Make sure the + and - ends of the


batteries line up correctly (inside of case is marked).

3. Close the cover.

ⓘ **Note:** If you are not going to use the remote control for a long time, remove the batteries.

### 3.3 Connect the antenna or cable

This section describes how to connect your TV to an antenna, cable, Direct Broadcast Satellite, and to a set-top box.



#### Connect to an antenna

Any DTV programs that are broadcast in your area can be received for free through an antenna connection.

Contact your local content provider or your local electronics retailer if you are unsure about what HDTV programs are available in your area.

Broadcasters are transitioning from analog to digital TV. This means that a given broadcaster can have channels available either in analog or in digital, or both analog and digital at the same time.

The TV has stereo sound if the broadcasting channel makes it available.

#### Connect to a cable

When your TV is connected to the cable socket, you may receive free digital and high definition programming (depending on your cable provider). Digital and high definition cable channels can be recognized by the format of the channel number. The channel number includes a dot "." For example, 11.1, 46.30, 108.201. Contact your cable provider for more information.

#### Connect to a Direct Broadcast Satellite (DBS)

There are two main DBS systems: DirecTV and DishNetwork. These systems require a separate, proprietary set-top box to decode signals and send them to the TV. The set-top box contains a digital TV tuner for receiving off-air digital television broadcasts.

Contact your local DBS provider for more information about the connections and the TV channels.

#### Connect to a set-top box

A cable box or satellite set-top box can be connected to the TV through the following connections:


- ANT
- A/V (Composite Video and Audio)
- S-Video

- YPbPr (Component Video Input)
- HDMI


For information about how to connect a set-top box, see the *Quick Start Guide* provided.

### Connect a set-top box through RF IN/OUT

If the TV is connected to a cable box or satellite set-top box via a coaxial connection, set the TV to channel 3 and 4, or the channel specified by the service provider.



### Connect a set-top box through component video input or HDMI




## 3.4 Connect the power cord

**⚠ WARNING:** Verify that your voltage corresponds with the voltage printed at the back of the TV. Do not insert the power cord if the voltage is different.

### To connect the power cord

1. Locate the power connector at the back of the TV.  
The location of the power connector varies according to TV model.



2. Insert the power cord fully into the TV power connector.
3. Connect the power cord plug to the power outlet. Ensuring that the cord is tightly secured at both ends.

### To disconnect the TV from the power outlet


The TV set is always connected to the power. You can disconnect the TV from the power by doing one of the following tasks:

- Unplug the power cord located at the back of the TV.
- Unplug the power cord from the power socket outlet.

Pull the power cord by the plug - do not pull on the power cord.


## 3.5 Manage cables

Route your power cord, antenna cable and all other device cables through the cable holder at the back of the TV. This holder helps keep your cables tidy and easily manageable.



### 3.6 Switch on and setup the TV

The TV switches on automatically after connecting the power cord.



Follow the on-screen instructions to select your language and complete your TV setup. Installation takes approximately 10 minutes.

**Note:** If you connect your TV to a cable box or satellite set-top box, you do not need to install channels. Press the red button on the remote control to exit the channel installation stage of the setup.

Finish the setup by selecting your location:

- If you choose **Retail store** your settings will be are erased each time you turn off the TV. This mode is only to be used for retail store displays.
- If you choose **Home** you are guided through a choice of picture display options. Use the left and right cursor to select your preferred screen.



## 4. Use your TV

This section helps you perform basic TV operations.

### 4.1 Switch your TV on/off or to standby

#### To switch the TV on

- Press **POWER** at the right side of the TV.



#### To switch to standby

- Press **POWER** on the remote control.

#### To switch on from standby without the remote control

- Press **POWER** at the right side of the TV to switch the TV off.
- Press **POWER** again to switch the TV on.

#### To switch off

- Press **POWER** at the right side of the TV.

#### Note

Energy consumption contributes to air and water pollution. When the power cord is plugged in, your TV consumes energy. Your TV has a very low standby power consumption.


## 4.2 Watch TV

### Switch channels

- Press a number (1 to 999) or press **CH+** or **CH-** on your remote control.

For digital channels, press a number (1 to 999) followed by a dot "." and then the corresponding sub channel number (1 to 999). Ex. 108.30.

- Press **PREV CH** to return to the previously viewed TV channel.




#### Note

You can also switch channels by pressing **CHANNEL -** or **+** on the side controls of the TV.

### Adjust volume

- Press **VOL+** or **VOL-** on your remote control.
- Press **MUTE** on your remote control to mute the sound.  
Press **MUTE** again or press **VOLUME -** or **+** to restore the sound.



**Note:** You can also adjust the volume by pressing **VOLUME -** or **+** on the side controls of the TV.

To increase the headphone volume, press the volume button on the TV or remote control. When headphones are plugged into the TV, the loud speakers are automatically muted.


---

### 4.3 Watch channels from a set-top box

1. Switch on the set-top box.  
The picture from your set-top box might appear automatically on your screen.
2. Use the remote control of your set-top box to select channels.

#### If the picture does not appear

1. Press **SOURCE** repeatedly to select the connected set-top box and wait a few seconds for the picture to appear.



2. Use the remote control of your set-top box to select channels.

---

### 4.4 Watch connected devices

1. Switch the connected device on.  
The picture from your connected device might appear automatically on the TV.

#### If the picture does not appear

1. Press **SOURCE** repeatedly to select the connected device and wait a few seconds for the picture to appear.

---

### 4.5 Watch a DVD

1. Insert a DVD disc in your player.
2. Press **Play ▶** on the remote control of your player.  
The picture from the player might appear automatically on your screen.


#### If the picture does not appear

1. Press **SOURCE** repeatedly to select the DVD player and wait a few seconds for the picture to appear.

## 5. Use more of your TV

This section describes the advanced features of your TV.

### 5.1 Understand the remote control



1. Switches the TV on from standby or back to standby. The TV is never powered off completely unless it is physically unplugged.
2. **FAVORITES**  
To display a list of all channels marked as favorite (including subchannels).
3. **FORMAT**  
Selects a picture format. See *Change picture format* on the next page.

4. **Color keys**  
Selects tasks.
5. **OPTION**  
Activates the quick access menu. For information, see *Use the quick access menu* on the next page.
6. **OK**  
To display the channel list or to activate a setting.
7. **Cursor buttons** ◀ ▶ ▲ ▼  
To navigate through the menus.
8. **INFO**  
Press to display information about the selected TV channel and program or accessory device. The quality and accuracy of the information on the information banner are transmitted from broadcasters. You may see a difference in broadcast time if the broadcaster is from a different time zone area.
9. **MUTE**  
Mutes or restores sound.
10. **+ CH - Channel up/down**  
Switches to the next or previous channel.
11. **SLEEP**  
To set a delay after which the TV switches to standby. For information, see *Set the sleeptimer* on page 16.
12. **Number keys 0-9**  
Selects a channel, page or setting.
13. **( . )**  
Press the dot (.) for digital channels.
14. **PREV CH**  
Returns to the previously-viewed channel.
15. **+VOL- Volume up/down**  
Increases or decreases volume.
16. **MENU / EXIT**  
Toggles the menu on or off.
17. **BACK**  
To return to the previous menu.
18. **SMART MODE**  
Toggles between preset picture and sound settings. For information, see *Use Smart Mode* on page 15.
19. **CC**  
Selects the different close caption modes.
20. **SOURCE**  
Selects connected devices.


## 5.2 Use the quick access menu

The quick access menu gives direct access to some often needed menu items.

### Note

When digital channels are installed and broadcast, the relevant digital options are displayed in the quick access menu.

1. Press **OPTION** on the remote control.



2. Press **▲** or **▼** and then **OK** to access one of the following menus:


- **Audio language**  
For digital channels only, where multiple audio languages are broadcast.
- **Closed captions**  
See *View closed captions (subtitles)* on page 20.
- **Picture format**  
See *Change picture format* on this page.
- **Equalizer**  
See *Change sound settings* on the next page.
- **Clock**  
See *Set the clock* on page 16.

## 5.3 Change picture and sound settings

### Change picture settings

This section describes how to adjust your picture settings.

1. Press **MENU** on the remote control.



2. Press **▶** to enter the **TV settings** menu.

MAGNAVOX	
TV menu	TV settings
TV settings	Picture
Features	Sound
Installation	

3. Press **▼** and **▶** to select the **Picture** menu.

MAGNAVOX	
TV menu	Picture
TV Settings	Picture
Picture	Contrast
Sound	Brightness
	Color
	Tint
	Sharpness
	Color temperature
	Dynamic contrast
	DNR

4. Press **▲** or **▼** to select one of the picture settings, and press **▶** to enter the setting.
5. Press **▲** or **▼** to adjust the setting, and press **◀** or **OK** to confirm the change.
6. Press **Menu** to exit.


### Summary of picture settings

The following picture settings can be configured. Depending on the format of the picture source, some picture settings might not be available.

- **Contrast** - Sets the level of white in the picture.
- **Brightness** - Sets the brightness of the picture.
- **Color** - Sets the level of saturation.
- **Tint** - Adjusts the color balance between red and green.
- **Sharpness** - Sets the sharpness of fine details.
- **Color temperature** - Sets the color temperature to normal, warm or cool.
- **Dynamic contrast** - Enhances contrast in the darker and the brighter picture areas as the image on the screen changes.
- **Digital Noise Reduction (DNR)** - Automatically filters out and reduces image noise and improves picture quality when receiving weak video signals. You can switch DNR on or off.
- **MPEG artifact reduction** - Smooths transitions on digital pictures. You can switch MPEG artifact reduction on or off.
- **Color enhancement** - Makes colors more vivid and improves the resolution of details in bright colors. You can switch color enhancement on or off.
- **Picture format** - Changes the format of the picture.
- **Horizontal shift** - Adjusts the horizontal position of the picture.
- **Vertical shift** - Adjusts the vertical position of the picture.

### Change picture format


1. Press **FORMAT** on the remote control.




2. Press **▲** or **▼** to select a picture format and press **OK** to confirm your choice.

## Summary of picture formats

The following picture formats can be selected. Depending on the format of the picture source, some picture formats might not be available.




**Automatic**  
(Not for PC mode.)  
Enlarges the picture automatically to best fit the screen. The subtitles remain visible.




**Super zoom**  
(Not for HD and PC mode.)  
Removes the black bars on the side of 4:3 broadcasts. There is minimal distortion.




**4:3**  
Shows the classic 4:3 format.



**Movie expand 14:9**  
(Not for HD and PC mode.)  
Scales classic 4:3 format to 14:9.



**Movie expand 16:9**  
(Not for HD and PC mode.)  
Scales the classic 4:3 format to 16:9.



**Wide screen**  
Stretches the classic 4:3 format to 16:9



**Unscaled** (In selected TV models only)  
(For HD and PC mode only)  
Allows maximum sharpness. Some distortion may be present due to the broadcaster's systems. Set your PC resolution to widescreen mode for best results.

## Change sound settings

This section describes how to adjust your sound settings.

1. Press **MENU** on the remote control and select **TV settings > Sound**.

TV menu		MAGNAVOX
TV Settings	Picture	Sound
Picture	Equalizer	
Sound	Balance	
	Digital audio language	
	Alternate audio	
	Mono/Stereo	
	AVL	
	BBE	
	Delta Volume	

2. Press **▲** or **▼** to highlight a sound setting and press **▶** to select the setting.
3. Press **▲** or **▼** to adjust the setting, and press **OK** to confirm the change.
4. Press **Menu** to exit.

## Summary of sound settings


The following sound settings can be configured. Depending on the sound source, some sound settings might not be available.

- **Equalizer**  
Changes the bass and treble. Select a bar to change the setting.
- **Balance**  
Sets the balance of the left and right speakers.
- **Digital audio language**  
Available for digital channels only, when multiple languages are broadcast. Lists available audio languages.
- **Alternate audio**  
Available for analog channels only when a main and second audio program (SAP) is available from the broadcaster. Select the main or second audio program.
- **Mono/Stereo**  
Select mono or stereo.
- **Automatic volume leveling (AVL)**  
Reduces sudden volume changes, for example, during commercials or when switching from one channel to another. Select on or off.
- **BBE**  
Restore clarity for better speech intelligibility and musical realism. Select on or off.
- **Delta volume**  
Levels out volume differences between channels or connected devices. Switch to the connected device as described in *Watch connected devices* on page 11 before changing the Delta volume.



## 5.4 Use Smart Mode

1. Press **SMART MODE** to set your TV to a predefined picture and sound setting.




2. Press **▲** or **▼** to select one of the following settings:
  - **Personal**  
The customized settings you defined by using the **Picture** menu.
  - **Sports**  
Vivid picture settings and clear sound for high action.
  - **Standard**  
For normal TV viewing.
  - **Movie**  
Brilliant picture settings for a cinematic experience.
  - **Game**  
Optimized for PCs, games consoles and playstations.
  - **Power saver**  
Eco friendly settings for lower power consumption.
3. Press **OK** to exit.

## 5.5 Create and use lists of favorite channels

This section describes how to create and use lists of your favorite channels.

### Select a list of favorite channels

1. Press the **FAVORITES** key on the remote control.



Your lists of favorite channels are displayed.

2. Press **▲** or **▼** to highlight a list, and press **OK** to select the list.

### Create or edit a list of favorite channels

1. Press the **FAVORITES** key on the remote control to display your lists of favorite channels.
2. Press **▲** or **▼** to highlight a list, and press **OK** to select the list.
3. Press the green key to enter **Edit** mode.  
A list of channels is shown.
4. Press **▲** or **▼** to highlight a channel.
5. Press **OK** to select or deselect the highlighted channel.  
The channel is added to or removed from the list of favorite channels.
6. Press the green key to exit.

### Switch to one of the channels on a list

1. Press the **OK** key on the remote control to display the last list that you selected.
2. Press **▲** or **▼** to highlight a channel.
3. Press **OK** select the channel.  
The TV switches to that channel.


## 5.6 Set the clock

This section describes how to set the time, date, time zone, and daylight saving.

### Set the time automatically

Some digital channels transmit the time. For these channels, you can set the time automatically. Follow these steps to set the time automatically and to choose which channel to read the time from.


1. Press **MENU** on the remote control and select **Installation > Clock > Auto clock mode**.
2. Select **Automatic**, and press **◀** to confirm your choice.



3. (Optional) Select the channel from which the TV will read the time.
  - Press **▼** and **▶** to enter the menu for **Auto clock channel**.
  - Press **▲** or **▼** to highlight a channel.
  - Press **◀** to confirm your choice.
4. (Optional) Select the time zone.
  - Press **▼** and **▶** to enter the menu for **Time zone**.
  - Press **▲** or **▼** to highlight the time zone.
  - Press **◀** to confirm your choice.
5. (Optional) Set daylight saving.
  - Press **▼** and **▶** to enter the menu for **Daylight saving**.
  - Press **▲** or **▼** to highlight **Automatic** or **Off**.
  - Press **◀** to confirm your choice.
6. Press **MENU** to exit.

### Set the time manually

1. Press **MENU** on the remote control and select **Installation > Clock > Auto clock mode**.
2. Press **▲** or **▼** to select **Manual**, and press **◀** to confirm your choice.




3. Press **▼** to select **Time** and then press **▶** to set the time. Use the format HH:MM. Select **AM/PM** for morning or afternoon.
4. Press **OK** to confirm your choice.
5. Press **▼** and **▶** to enter the menu for **Day**.
6. Press **▲** or **▼** to select the day.
7. Press **OK** to confirm your choice.
8. Press **MENU** to exit.

## 5.7 Set the sleeptimer

This section describes how to program the TV to switch off automatically after a delay.

1. Press **MENU** on the remote control and select **Features > Sleptimer**.



2. Press **▲** or **▼** to select a value from **0** to **180** minutes. For example, when you select **90**, the TV switches to standby in 90 minutes.
3. Press **MENU** to exit.

### ✳ Tip

To turn the sleeptimer off, select **0** minutes.

## 5.8 Use child control and rating locks

This section describes how to lock or unlock the TV. You can set a personal identification number (PIN) and prevent your children from watching certain programs or certain channels.

### Set or change your PIN

1. Press **MENU** on the remote control and select **Features > Change PIN**.
2. Enter a 4-digit PIN with the number keys on the remote control.
  - If you have a PIN, enter your current PIN.
  - If you do not have a PIN or if you have lost your PIN, enter **0711**.
3. Enter your new 4-digit PIN and then enter it again to confirm. A message appears to confirm that your PIN has been changed.
4. Press **MENU** to exit.

### Lock the TV

This section describes how to lock all channels on the TV. At the specified time, screen is blanked out and the audio is muted.

1. Ensure that the clock is set with the current time. For information about how to set the clock, see *Set the clock* on the previous page.
2. Press **MENU** on the remote control and select **Features > Child lock > Lock after**.
3. Enter your PIN.
 

If you do not have a PIN, set one as described in *Set or change your PIN* on this page.
4. Press **▶** to select **Timer**.

TV menu   Features   Child lock		MAGNAVOX
Lock after	Timer	
Timer	Off	
Time	On	

5. Press **▼** to select **On** and activate the **Lock after** feature. Selecting **Off** deactivates the feature.
6. Press **◀** to confirm your choice.
7. Press **▼** to select **Time** and then press **▶** to set the time. Use the format HH:MM. Select **AM/PM** for morning or afternoon.
8. Press **OK** to confirm the time.
9. Press **MENU** to exit.
10. Restart your TV to activate this function.

### Lock a channel

This section describes how to lock specified channels. The channels can be selected but the screen is blanked out and the audio is muted.

1. Press **MENU** on the remote control and select **Features > Child lock > Channel lock**.
2. Enter your PIN.
 

If you do not have a PIN, set one as described in *Set or change your PIN* on this page.

TV menu   Features		MAGNAVOX
Child Lock	Channel lock	
Lock after	<input type="checkbox"/>	Channel 1 Sport
Channel lock	<input type="checkbox"/>	Channel 2 News
TV ratings lock	<input type="checkbox"/>	Channel 3 Movies
Movie ratings lock	<input type="checkbox"/>	Channel 4
Canada English ratings lock	<input type="checkbox"/>	Channel 5
Canada French ratings lock	<input type="checkbox"/>	Channel 6
Region ratings lock	<input type="checkbox"/>	Channel 7

3. Press **▲** or **▼** and then press **OK** to lock one or more channels or external sources.
 

Each channel has a box-graphic in front of it to indicate whether it is locked:

  - A box with **X** indicates that the channel is locked
  - An empty box indicates that the channel is not locked
4. Press **MENU** to exit.

**Use the TV ratings lock**

Your TV is equipped with a V-chip that allows you to control access to individual programs based on their age rating and content rating. The program content advisory data are sent by the broadcaster or by the program provider.

If you are receiving channels through a set-top box or cable box connected by HDMI, you cannot use the TV ratings lock. Your set-top box or cable box must be connected through RF or AV connectors.

1. Press **MENU** on the remote control and select **Features > Child lock > TV ratings lock**.

2. Enter your PIN.

If you do not have a PIN, set one as described in *Set or change your PIN* on the previous page.

3. Press **▲** or **▼** and then press **OK** to lock or unlock one or more ratings.

Each rating has a box-graphic in front of it to indicate whether programs carrying that rating are currently locked:

- A box with **X** indicates that all items in the content ratings list are locked.
- An empty box indicates that the item is not selected.
- A box with **/** indicates that some content ratings are deselected. For example, for rating TV-14, you can deselect one or more of the following content ratings: Dialog (D), Language (L), Sex (S), or Violence (V).

TV menu   Features   Child Lock		<b>MAGNAVOX</b>	
TV ratings lock		TV-14	
<input type="checkbox"/> All	<input type="checkbox"/> (D)Dialog	<input checked="" type="checkbox"/> (L)Language	
<input type="checkbox"/> None	<input checked="" type="checkbox"/> (S)Sex	<input checked="" type="checkbox"/> (V)Violence	
<input type="checkbox"/> TV-Y			
<input type="checkbox"/> TV-Y7			
<input type="checkbox"/> TV-G			
<input type="checkbox"/> TV-PG			
<input checked="" type="checkbox"/> TV14			
<input checked="" type="checkbox"/> TV-MA			

- When you select **All**, all items in the ratings list are locked.
- When you select **None**, programs with no rating and programs with a rating of **None** are locked.
- When you lock a rating, all ratings in the younger age categories are automatically locked.

4. Press **MENU** to exit.

**Summary of TV ratings**

Age rating	Content rating
<b>All</b>	None
<b>None</b>	None
<b>TV-Y</b> Appropriate for children of all ages with themes and elements suitable for children aged 2-6.	None
<b>TV-Y7</b> Programs designed for children age 7 and older.	Fantasy Violence (FV)
<b>TV-G</b> Programs suitable for all ages. These programs contain little or no violence, no strong language and little or no sexual dialog or situations.	None
<b>TV-PG</b> Programs contain elements that some parents may find unsuitable for younger children and which may need parental guidance. The program may contain moderate violence, sexual dialog and/or situations and some strong language.	Dialog (D) Language (L) Sex (S) Violence (V)
<b>TV-14</b> Programs contain elements that may not be suitable for children under 14 years of age. These programs include one or more of the following: intense violence, intense sexual situations, suggestive dialog and strong language.	Dialog (D) Language (L) Sex (S) Violence (V)
<b>TV-MA</b> Programs are designed to be viewed by adults and may be unsuitable for children under the age of 17. These programs may contain graphical violence, explicit sexual activity and/or crude or indecent language.	Language (L) Sex (S) Violence (V)

## Use the movie ratings lock

This section describes how to control viewing of movies based on their Motion Picture Association of America (MPAA) rating.

1. Press **MENU** on the remote control and select **Features > Child lock**.
2. Select one of the menus for movie ratings lock.
  - In the USA, select **Movie ratings lock**.
  - In Canada, select **Canada English ratings lock** or **Canada French ratings lock**.
3. Enter your PIN.

If you do not have a PIN, set one as described in *Set or change your PIN* on page 17.

The following screen shows the ratings in **Movie ratings lock**.

TV menu   Features <span style="float: right;">MAGNAVOX</span>	
Child Lock	Movie ratings lock
Lock after	<input checked="" type="checkbox"/> All
Channel lock	<input checked="" type="checkbox"/> NR
TV ratings lock	<input type="checkbox"/> G
Movie ratings lock	<input checked="" type="checkbox"/> PG
Canada English ratings lock	<input checked="" type="checkbox"/> PG-13
Canada French ratings lock	<input checked="" type="checkbox"/> R
Region ratings lock	<input checked="" type="checkbox"/> NC-17
	<input checked="" type="checkbox"/> X

4. Press **▲** or **▼** and then press **OK** to lock or unlock one or more movie ratings.

Each rating has a box-graphic in front of it to indicate whether it is locked:

- A box with **X** indicates that the rating is locked
- An empty box indicates that the rating is not locked

When you lock a movie rating, all items for ages below that movie rating are automatically locked.

5. Press **MENU** to exit.

## Summary of US movie ratings

Movie rating	Description
<b>All</b>	All items in the ratings list are locked.
<b>NR</b>	Not rated.
<b>G</b>	Movies with a mild content, suitable for all ages.
<b>PG</b>	Movies for which parental guidance is recommended. They may contain a few racy or violent scenes or maybe some bad language.
<b>PG -13</b>	Movies for which parental guidance may be recommended if under age 13.
<b>R</b>	Restricted. The movies usually contain offensive sex or bad language and may be unsuitable for children under the age of 17. Parental guidance or permission needed.
<b>NC-17</b>	Even with parental permission, forbidden under age 17. More offensive sex, violence or bad language.
<b>X</b>	Movies which generally focus on sex, violence and/or bad language. Also known as pornography.

## Summary of Canadian movie ratings

Movie rating	Description
<b>All</b>	All items in the ratings list are locked.
<b>C</b>	Programming suitable for children under the age of 8 years. No profanity or sexual content of any level allowed. Minimal comedic violence.
<b>C8+</b>	Suitable for children ages 8 and over. Low intensity violence and fantasy horror allowed.
<b>G</b>	Movies with a mild content, suitable for all ages.
<b>PG</b>	Movies for which parental guidance is recommended. They may contain a few racy or violent scenes or maybe some bad language.
<b>14+</b>	Programming intended for children ages 14 and over. May contain intense scenes of violence, strong profanity, and depictions of sexual activity within the context of a story.
<b>18+</b>	Programming intended for viewers ages 18 and over. May contain strong violence, language, and sexual activity.

## Summary of Canadian French movie ratings

Movie rating	Description
<b>All</b>	All items in the ratings list are locked.
<b>G</b>	Appropriate for all ages with little or no violence and little to no sexual content.
<b>8 ans+</b>	Appropriate for children 8 and up which may contain little violence, some foul language and/or little to no sexual content.
<b>13 ans+</b>	Appropriate for children 13 and up, with moderate violence, language, and some sexual situations. Persons under 13 should be accompanied by an adult.
<b>16 ans+</b>	Appropriate for children 16 and up, with strong violence, strong language, and strong sexual content.
<b>18 ans+</b>	Only to be viewed by adults and contains extreme violence and graphic sexual content/pornography.

## Use the region ratings lock

This section describes how to control access to digital programs based on downloaded region ratings.

Before you download a ratings table, ensure that regional ratings are broadcast.

1. Press **MENU** on the remote control and select **Installation > Preferences > Downloaded rating table**.

TV menu   Installation		MAGNAVOX
Preferences	Downloaded rating table	
Location	Off	
Show emergency alerts	On	
Downloaded rating table		

2. Press **▲** or **▼** to select **On**, and press **◀** to confirm your choice. If you select **Off**, you choose not to download the region rating table and you cannot use the region rating lock.
3. Press **◀** to return to the TV menu and select **Features > Child lock > Region ratings lock**.

TV menu   Features		MAGNAVOX
Child Lock	Region ratings lock	
Lock after		
Channel lock	Please enter your PIN	
TV ratings lock		
Movie ratings lock		
Canada English ratings lock		
Canada French ratings lock		
Region ratings lock		

4. Enter your PIN.  
If you do not have a PIN, set one as described in *Set or change your PIN* on page 17.
5. Press **▲** or **▼** and then press **OK** to lock or unlock one or more ratings.  
Each rating has a box-graphic in front of it to indicate whether it is locked:
  - A box with **X** indicates that the rating is locked
  - An empty box indicates that the rating is not locked
6. Press **MENU** to exit.

## 5.9 View closed captions (subtitles)

The caption service displays transmitted CC-, T-, and CS- text. The caption text can be displayed permanently or only when the TV is muted. This section describes how to use the caption service.

### Note

- This television provides a display of television closed captioning that conforms with the EIA-608 standard and in accordance with Sections 15.119 of the FCC rules.
- If you connect your set-top box via HDMI or component video input, you cannot select closed caption through the TV. You can select closed caption through the set-top box only.
- The captions do not always use correct spelling and grammar.
- Not all TV programs and product commercials include closed caption information. Refer to your area TV program listings for the TV channels and times of closed caption shows. The captioned programs are usually noted in the TV listings with service marks such as 'CC'.

### Display captions

1. Press **MENU** on the remote control and select **Features > Caption settings > Closed captions**.
2. Press **▲** or **▼** to select **On**, **Off** or **On during mute**, and press **◀** to confirm your choice.
3. Press **MENU** to exit.

### Select caption services

For information about the caption services see *Summary of caption services* on the next page.

1. Turn captions on as described in *Display captions* on this page.
2. Select a caption service for analog channels:
  - Press **MENU** on the remote control and select **Features > Caption settings > Caption service**.
  - Press **▲** or **▼** to select one of the listed caption services and press **◀** to confirm your choice.  
Not all caption services are necessarily being used by a TV channel during the transmission of a closed caption program.
3. Select a caption service for digital channels:
  - Press **▼** and **▶** to enter the menu for **Digital caption service**.
  - Press **▲** or **▼** to select one of the listed caption services, and press **◀** to confirm your choice.
4. Press **MENU** to exit.

### Summary of caption services

- **CC-1, CC-2, CC-3, and CC-4**  
Dialog and descriptions for the action on the captioned TV program show on screen. Usually **CC 1** is the most used. **CC 2** can be used for alternate languages if they are being transmitted.
- **T-1, T-2, T-3 and T-4**  
Often used for channel guide, schedules, bulletin board information for Closed Captions programs, news, weather information, or stock market reports.
- **CS-1, CS-2, CS-3, CS-4, CS-5 and CS-6**  
Service 1 is designated as the Primary Caption Service. This service contains verbatim, or near-verbatim captions for the primary language being spoken in the accompanying program audio.  
Service 2 is designated as the Secondary Language Service. This service contains captions in a secondary language which are translations of the captions in the Primary Caption Service. The other service subchannels are not pre-assigned. It is up to the discretion of the individual caption provider to utilize the remaining service channels.

### Choose how digital captions are displayed

You can define the size, font, color, background and other characteristics of the caption text.

1. Press **MENU** on the remote control and select **Features > Caption settings > Digital caption options**.
2. Press **▲** or **▼** to highlight an option for digital captions, and press **▶** to select the option.
3. Press **▲** or **▼** to highlight a setting for the option, and press **◀** to confirm your choice.
4. Press **MENU** to exit.

## 5.10 Use your TV in HDTV mode

Not all models can be configured in HDTV mode. For information about your set, see the specification.

When you connect a high definition (HD) device to your TV, you must configure the display format of your TV. You might also have to configure the display format of your HD device. For information about configuring your device, see the documentation of the device.

### Supported video formats

The following video formats are supported in HDTV mode:

Resolution	Refresh rate
640 x 480p	60Hz
720 (1440) x 480i	60Hz
720 (1440) x 576i	50Hz
720 x 480p	60Hz
720 x 576p	50Hz
1280 x 720p	50Hz, 60Hz
1920 x 1080i	50Hz, 60Hz
1920 x 1080p	24Hz, 25Hz, 30Hz, 50Hz, 60Hz

### Note

Your TV is HDMI compliant. If you do not get a good picture, change the video format on your connected devices.

### Configure your TV in HDTV mode

1. Connect the HD device to your TV as described in *Connect your devices* on page 28.
2. Press **MENU** on the remote control and select **Features > Mode Selection**.

TV menu		MAGNAVOX
Features	Mode Selection	
Mode Selection	PC	
Caption settings	HDTV	
Sleeptimer		
Child lock		
Change PIN		

3. Select **HDTV** and press **◀** to confirm your choice.
4. If necessary, adjust the TV picture settings as described in *Change picture and sound settings* on page 13.
5. Press **MENU** to exit.

### Note

**Mode Selection** appears for the following input signals only:

- 720x480p@60Hz
- 1280x720p@60Hz
- 1920x1080p@24/25/30/50/60 Hz

## 5.11 Use your TV as a PC monitor

For information how to connect a PC to your TV see *Connect a PC* on page 30. Use an HDMI-DVI cable or an HDMI-DVI adaptor. For sound, add an audio cable with a stereo mini jack.

### Caution

Before you connect your PC, set the PC monitor refresh rate to 60Hz.

### Supported screen resolutions


The following screen resolutions are supported in PC mode:

Resolution	Refresh rate
640 x 480	60Hz
800 x 600	60Hz
1024 x 768	60Hz
1280 x 768	60Hz
1280 x 1024	60Hz
1360 x 768	60Hz
1920 x 1080	60Hz

If necessary, you can adjust the picture position to the center of the screen with the cursor buttons.

### Configure your TV in PC mode

1. Connect the PC to your TV as described in *Connect a PC* on page 30.
2. Press **MENU** on the remote control and select **Features > Mode Selection**.



TV menu		MAGNAVOX
Features	Mode Selection	
Mode Selection	PC	
Caption settings	HDTV	
Sleeptimer		
Child lock		
Change PIN		

3. Select **PC** and press **OK** to confirm your choice.
4. If necessary, adjust the picture settings as described in *Change picture settings* on page 13.

 **Tip:** Set the picture format to Unscaled when using wide-screen PC resolutions.

5. Press **MENU** to exit.

### Note

**Mode Selection** appears for the following input signals only:

- 720x480p@60Hz
- 1280x720p@60Hz
- 1920x1080p@24/25/30/50/60 Hz



## 6. Change your TV installation

The first time you switch on your TV you select the language for the TV menus and make basic choices for picture and sound settings. Use this chapter to reinstall the TV, to set preferences in the TV menus, or to tune new TV channels.

### 6.1 Select your menu language

1. Press **MENU** on the remote control and select **Installation > Language**.

TV menu		MAGNAVOX
Installation	Language	
Language	<input type="radio"/> English	
Channels	<input type="radio"/> Français	
Preferences	<input type="radio"/> Español	
Source labels		
Clock		
Current software info		
Reset AV settings		

2. Select a language and press **OK** to confirm your choice.
3. Press **◀** to return to the **Installation** menu.

### 6.2 Set your location to home

You can set the location of your TV to **Home** or **Retail store**. Choosing **Home** gives you full flexibility to change predefined settings for picture and sound.

1. Press **MENU** on the remote control and select **Installation > Preferences > Location**.
2. Select **Home** and press **OK** to confirm your choice.
3. Press **◀** to return to the **Installation** menu.

### 6.3 Tune channels automatically

This section describes how to search for and store channels automatically. Before you tune channels, ensure that you are registered with your cable TV provider and that your equipment is correctly connected.


1. Press **MENU** on the remote control and select **Installation > Channels > Autoprogram > Start Now**.

TV menu   Installation		MAGNAVOX
Channels	Autoprogram	
Autoprogram		
Weak channel installation	Start Now	
Installation mode		
Uninstall channels		

2. Press **OK** to start the installation.  
If you run **Autoprogram** when you have locked channels, a message appears asking to enter your PIN code. Enter your PIN code in order to complete the installation.

If you have forgotten your PIN, reset it as described in *Set or change your PIN* on page 17.

3. Select **Cable** or **Antenna** and press **OK**.
  - When **Antenna** is selected, the TV detects antenna signals. It searches for NTSC and ATSC channels available in your area.
  - When **Cable** is selected, the TV detects signals supplied by cable. It searches for NTSC, ATSC, and QAM modulated channels available in your area.



When autoprogramming is complete, this message appears "**Channel search completed**".

4. Follow the on-screen instructions to complete the installation.

### 6.4 Optimize the signal quality from your antenna

You can optimize your signal quality by tuning in ATSC channels with weak signals, and adjusting the antenna.

1. Press **MENU** on the remote control and select **Installation > Channels > Installation mode**.
2. Select **Antenna** and press **◀** to confirm your choice.
3. Press **▲** and **▶** to enter **Weak channel installation**.
4. Highlight a channel from the list of TV channels and press the green color button on the remote control. The signal strength for the channel is displayed.
5. Adjust your antenna to maximize the signal strength.
6. Press **MENU** to exit.

## 6.5 Uninstall and reinstall channels

This section describes how to uninstall and reinstall a stored channel. When a channel is uninstalled it is removed from the list of channels.

Uninstalled channels are not reinstalled during an installation update.

1. Press **MENU** on the remote control and select **Installation > Channels > Uninstall channels**.

TV menu   Installation		MAGNAVOX	
Channels	Uninstall channels		
Autoprogram	<input type="checkbox"/>	52	
Weak channel installation	<input type="checkbox"/>	53	
Installation mode	<input checked="" type="checkbox"/>	54	
Uninstall channels	<input type="checkbox"/>	55	
	<input type="checkbox"/>	56	
	<input type="checkbox"/>	57	
	<input type="checkbox"/>	58	
	<input type="checkbox"/>	59	

2. Press **▶** to enter the list of stored channels.
3. Press **▲** or **▼** to select the channel you want to uninstall, and press the green key on the remote control.  
The channel is removed from the channel list. Press the green key again to reinstall the channel.
4. Press **MENU** to exit.

## 6.6 Return your settings to default values

This section describes how to return picture and sound settings to their default values. The channel installation settings are not affected.

1. Press **MENU** on the remote control and select **Installation > Reset AV settings**.

TV menu		MAGNAVOX	
Installation	Reset AV settings		
Language			
Channels			Start now
Preferences			
Source labels			
Clock			
Current software info			
Reset AV settings			

2. Press **▶** to highlight **Start now**, and press **OK** to reset the AV settings.
3. Press **Menu** to exit.

## 6.7 Show emergency alerts (EAS)

The SCTE18 standard defines an emergency alert signalling method for use by cable TV systems. EAS can be broadcast to digital devices such as digital set-top boxes, digital TVs, and digital VCRs.

The EAS scheme allows a cable operator to disseminate information related to state and local emergencies and warnings.

EAS contain the following information:

- Emergency alert text
- Start time and date
- End time and date
- Priority

EAS with priority **Maximum** or **High** are always displayed on your TV. However, you can configure your TV to not show EAS messages with **Medium** or **Low** priority.

EAS is not possible with a multimedia browser or with analog video sources.

You can always remove the message from the screen. The message display overlaps menus and other messages on the screen.

### Configure emergency alerts

1. Press **MENU** on the remote control and select **Installation > Preferences > Show emergency alerts**.

TV menu   Installation		MAGNAVOX	
Preferences	Show emergency alerts		
Location			Always
Show emergency alerts			Skip low priority
Downloaded rating table			Skip medium/low priority

2. Highlight one of the following options:
  - **Always**  
To display all emergency alert messages
  - **Skip low priority**  
To show all messages except low priority messages
  - **Skip medium/low priority**  
To show maximum and high priority messages only
3. Press **◀** to confirm your choice.
4. Press **MENU** to exit.

## 7. Update your TV software


Magnavox continuously tries to improve its products and we strongly recommend that you update the TV software when updates are available.

New software can be obtained from your dealer or downloaded from the [www.magnavox.com/usasupport](http://www.magnavox.com/usasupport) website. Use the type number of your TV (e.g. 42MF438B/27) to find information.

For information about using a USB device, see *Notes for the use of USB devices* on page 33.

### 7.1 Check your current software version

1. Press **MENU** on the remote control and select **Installation > Current software info**.



The version and a description of the current software is displayed.

### 7.2 Prepare for the software upgrade

You require the following equipment:

- A PC with web browsing capability.
- An archive utility that supports the ZIP-format (e.g. WinZip for Windows or StuffIt for Mac OS).
- A USB memory stick.

#### Note:

- Only FAT/DOS-formatted portable memory is supported.
- New software can be obtained from your dealer or can be downloaded from the [www.magnavox.com/usasupport](http://www.magnavox.com/usasupport) website.
- Use only software upgrades that can be found on the Magnavox web site.

#### Warning:

- Do not remove the USB device during the software upgrade.
- If there is a power drop during the upgrade, do not remove the USB device from the TV. The TV will continue the upgrade as soon as the power comes back.
- If you try to upgrade to a software version lower than the current version, a confirmation message will be displayed. Downgrading to older software should be done only in case of real necessity.
- If an error occurs during the upgrade, retry the procedure or contact your dealer.


### Download the software


1. On your PC, open a web browser and go to [www.magnavox.com/usasupport](http://www.magnavox.com/usasupport).
2. Find information and software related to your TV and download the latest software upgrade file to your PC.
3. Decompress the ZIP-file and copy the “**autorun.upg**” file to the root directory of your the USB device.

### 7.3 Upgrade software

1. Prepare the software upgrade as described above.
2. Connect your USB device to the USB port on the side of your TV. The TV scans the USB device for the updated software and automatically enters the upgrade mode.
3. Read the instructions on-screen and confirm that you want to continue with the installation.


You see a screen similar to this.



4. When the software upgrade is complete, remove the USB device.
5. Disconnect the TV from the power socket outlet.
6. Reconnect the TV to the power socket outlet.
7. Press **Power**  at the side of the TV to switch the TV on. The TV starts up with the new software.

## 8. Connect devices

### 8.1 Connection overview




1. **Antenna input**
2. **AV1**  
Component video input. Y Pb Pr and Audio L/R connectors for DVD, digital receiver or game console, etc.
3. **AV2**  
Second component video input.
4. **AV3**  
Composite video input to be used together with Audio L/R connectors for camcorder, game console, etc.
5. **Service UART**  
For use only by authorized service personnel.
6. **SPDIF Out**  
Digital audio out.
7. **DVI Audio IN for HDMI 3.**
8. **HDMI 3 In**  
HDMI in connector for Blu-ray Disc player, HD digital receiver or HD game console, etc.
9. **S-Video (AV3)**  
S-Video input connector to be used together with Audio L/R connectors for camcorder, game console, etc.
10. **HDMI 2 In**  
Second HDMI in connector.
11. **HDMI 1 In**  
First HDMI in connector.
12. **Headphones**  
Stereo Mini Jack.
13. **Video (Side)**  
Video input cinch connector to be used together with Audio L/R connectors for camcorder, game console, etc.
14. **S-Video (Side)**  
S-Video input connector to be used together with Audio L/R connectors for camcorder, game console, etc.
15. **HDMI 4 In (Side)**  
HDMI in connector for Blu-ray Disc player, HD digital receiver or HD game console, etc.
16. **USB**  
USB connector.

**Note:** When you use the S-Video (AV3) for video signals, do not use the composite video input on AV3 for video signals.

## 8.2 Select your connection quality

This section describes how you can enhance your audio visual experience by connecting your devices with the best possible connectors.

### HDMI - Highest quality



HDMI produces the best audio visual quality possible. Both audio and video signals are combined in one HDMI cable, providing an uncompressed, digital interface between your TV and HDMI devices. You must use HDMI to experience full high definition video. Use only a certified HDMI cable.

**Tip**

If your device only has a DVI connector, use a DVI-HDMI adaptor to connect your device to a HDMI connector on the TV. As such a connection does not support sound, you must connect a separate audio cable from the device to the Audio L/R input connectors on the TV.


**Note**

Magnavox HDMI supports High-bandwidth Digital Contents Protection (HDCP). HDCP is a form of Digital Rights Management that protects high definition content in DVD or Blu-ray discs.


### Component (YPbPr) - High quality

Component (Y Pb Pr) video provides better picture quality than S-Video or composite video connections. Though component video supports high definition signals, picture quality is lower than HDMI and is analog.

When connecting a component video cable, match the cable colors to the connectors on the back of the TV. Also, connect an Audio L/R cable to the red and white Audio L/R input connectors.




Component video cable  
- Red, Green, Blue




Audio L/R cable  
- Red, White

### S-Video - Good quality

An analog connection, S-Video provides better picture quality than composite video. When connecting your device with S-Video, plug the S-Video cable to the S-Video connector on the side of the TV. You must connect a separate Audio L/R cable from the device to the red and white Audio L/R in/out connectors on the side of the TV.




S-Video cable



Audio L/R cable  
- Red, White

### Composite - Basic quality

Composite video provides basic analog connectivity, usually combining a (yellow) video cinch cable with (red and white) Audio L/R cinch cable. Match the cable colors when connecting to the composite video and audio L/R input connectors on the side of the TV.



Composite audio/video cable  
- Yellow, red and white

## 8.3 Label your connections

When you connect devices, you can label the connections to help you to later identify where devices are connected.

1. Press **MENU** on the remote control and select **Installation > Source Labels**.

MAGNAVOX	
Installation	Source labels
Language	AV1
Channels	AV2
Preferences	AV3
Source labels	HDMI1
Clock	HDMI2
Reset AV settings	HDMI3
Software upgrade	Side HDMI
	Side AV

2. Press **▶** to enter the list of available connections.
3. Press **▲** or **▼** to highlight a connection in the list.
4. Press **▶** to enter the list of devices for the connection, and press **▲** or **▼** to highlight a device.
5. Press **◀** to confirm your choice.
6. Press **MENU** to exit.

## 8.4 Connect your devices


This section describes how to connect a selection of devices with different connectors. Note that different types of connectors may be used to connect a device to your TV. The following sections describe examples only, other configurations are possible.

When connecting composite or component cables, match the cable colors to the connectors on the TV.


### Connect a set-top box and a DVD player/recorder via composite connectors

#### Warning

Do not place your recorder too close to the screen because some recorders can be susceptible to signals.



### Connect a DVD recorder or VCR and a second A/V device via composite connectors




If your recorder has an S-VHS video jack: for improved picture quality, connect an S-Video cable with the S-Video input and connect the audio cables to the audio L and R input jacks of AV3/side AV.

#### Note


When you use an S-Video connector, do not connect any device to the AV3/side AV video jack.

If you use mono equipment, the left loudspeaker reproduces sound but the right speaker does not. Use a mono to stereo adapter (not supplied) for sound reproduction via all internal loudspeakers.


### Connect a set-top box, DVD player/recorder and game console via HDMI



### Connect a DVD player/recorder via HDMI-DVI and DIGITAL AUDIO OUT connectors




### Connect a DVD player via S-Video and audio connectors



#### Warning

When using the S-Video (AV3) connector, do not connect any device to the AV3 composite video input.

**Connect a set-top box via a composite connector**



If your device has an S-VHS video jack: For improved picture quality, connect a S-Video cable with the S-Video input of AV3/side AV and connect the audio cables to the audio L and R input jacks of AV3/side AV.


**Warning**

When using the S-Video connector do not connect any device to the video jack of AV3 or the side AV.


Only the left loudspeaker reproduces sound for mono equipment. Use a mono to stereo adapter (not supplied) for sound reproduction via all internal loudspeakers.

**Connect a DVD player/recorder via component video output connectors (YPbPr) and analog audio**

Selected TV models are capable of displaying 1080i, 1080p, 720p and 480p DTV signals when connected to a DTV tuner cable box. Select the output of the cable box to either 1080i, 1080p, 720p or 480p. A DTV signal must be available in your area.



**Connect a digital home theater amplifier**




**Warning**


Due to legal requirements, it is possible that with certain copy protected PCM audio qualities from a accessory device connected to the HDMI input, the digital audio signal is muted.

**Connect a PC**


Connect a PC with an S-Video connector at the back




Connect a PC with an HDMI connector



Connect a PC with an S-Video connector at the side



Connect a PC with a DVI connector





## 9. Glossary

Term		Meaning
<b>DVI</b>	Digital Visual Interface	A digital interface standard created by the Digital Display Working Group (DDWG) to convert analog signals into digital signals to accommodate both analog and digital monitors.
<b>RGB signals</b>	Red, Green and Blue signals	These are the three video signals, red, green & blue, which make up the picture. Using these signals improves picture quality.
<b>S-VHS signals</b>	Super-VHS signals	These are 2 separate Y/C video signals from the S-VHS and Hi-8 recording standards. The luminance signals Y (black and white) and chrominance signals C (color) are recorded separately on the tape. This provides better picture quality than with standard video (VHS and 8 mm) where the Y/C signals are combined to provide only one video signal.
<b>16:9</b>	TV format	Refers to the ratio between the length and height of the screen. Wide screen televisions have a ratio of 16 by 9, conventional screen TV sets have a ratio of 4 by 3.
<b>HDMI</b>	High definition Multimedia Interface	Provides an uncompressed, all digital audio/video interface between the TV and any HDMI-equipped audio/video component, such as set-top box, DVD player and A/V receiver. HDMI supports enhanced or high definition video plus two-channel digital audio.
<b>System</b>		Television pictures are not broadcast in the same way in all countries. There are different standards: BG, DK, I, and LL'. The System setting is used to select these different standards. This is not to be confused with PAL or SECAM color coding. PAL is used in most countries in Europe, Secam in France, Russia and most African countries. The United States and Japan use a different system called NTSC. The inputs AV1 and AV2 are used to read NTSC coded recordings.
<b>HDCP</b>	High-bandwidth Digital Content Protection	A specification developed by Intel for protecting digital entertainment that uses the DVI interface. HDCP encrypts content the transmission of digital content between the video source or transmitter such as a computer, DVD player or set-top box and the digital display or receiver such as a monitor, television or projector.
<b>BBE</b>	Barcus Berry Electronics	A sound enhancement technology.

## 10. Troubleshooting

Symptoms	Possible cause	What should you do
No power or indicator light.	The TV is not connected to the power.	1. Press <b>POWER</b> at the right side of the TV, or press <b>POWER</b> on the remote control.
		2. Ensure the power cord is connected tightly to the TV power connector and to the power socket outlet.
		3. Remove the power cord from the power socket outlet, wait 60 seconds and reconnect the power cord.
		4. Connect the TV to a different power socket outlet.
Error message on the screen with HDMI connection.	HDCP authentication fail.	1. Ensure that your HDMI cable is certified.
		2. Press <b>SOURCE</b> on the remote control to switch to another source and then switch back to the HDMI source.
		3. Reset the accessory device and the TV. <ul style="list-style-type: none"> <li>• Turn on the TV</li> <li>• Select the HDMI channel</li> <li>• Turn on the accessory device</li> </ul>
		4. While the TV and the accessory device are powered on, unplug either end of the HDMI cable and then reinsert the cable.
No sound is detected from the PC.	Incorrect HDMI port is connected.	1. Connect a DVI-HDMI cable to the HDMI 3 port on the TV.
	Audio cable is not connected.	2. Connect an audio cable to the DVI AUDIO IN port on the TV.
		3. Press <b>SOURCE</b> on the remote control, and select the HDMI 3 source.
TV does not respond to the remote control.	Batteries are installed incorrectly, or low battery power.	1. Ensure the indicator light on the TV blinks when the remote control buttons are pressed.
		2. Ensure that you are using the remote control supplied with the TV.
		3. Ensure that the batteries of the remote control are inserted according to the illustration on the remote control and that the batteries do not need to be replaced.
		4. Remove the power cord from the power socket outlet, wait 60 seconds and reconnect the power cord.
The picture is distorted. It is stretched out, has short, fat, black bars on the side or top.	Broadcast video format.	1. Press the <b>FORMAT</b> button on the remote control to select the best picture format.
		2. For some accessory devices, the picture format has to be set in the accessory device.
The picture is mostly red and green, or the picture is missing red when the TV is connected to an accessory device via component cables.	Insecure/incorrect connection.	1. Ensure all the connections are made according to the color code. 2. Push the component cables all the way into the YPbPr sockets on the TV.
No sound on the TV loudspeaker.	Volume level is set to zero.	1. Increase the volume.
	Sound is muted.	2. Press <b>MUTE</b> on the remote control.
	Headphones are connected.	3. Ensure the headphones are not plugged into the TV.
	Audio cable is not connected.	4. For AV connection, ensure that the Audio L/R cable is connected as described in <i>Connect your devices</i> on page 28. If you are using a component cable, ensure that you have not crossed the red audio cable with the red video cable.
	Accessory device audio output setting is incorrect.	5. For HDMI connections, some accessory devices have an HDMI audio output setting that must be turned on for HDMI to HDMI connections.
Bad picture quality with a coaxial connection.	Standard definition channels are not as clear as high definition channels.	1. Connect the devices via component or HDMI cables.
No picture or sound.	Incorrect channel	1. Ensure you have selected the correct channel.
	Incomplete channel installation.	1. If the TV receives channels via an AV connection, set the TV to the correct source input.
2. If the TV is connected directly to the wall via a coaxial connection, perform the auto-installation again.		

---

## 11. Notes for the use of USB devices

### Digital Content Issues

- Only FAT (DOS) formatted (initialized) portable memory is supported. Errors in this formatting can result in unreadable content. If such problems appear try to re-format the card. Be aware that formatting the card will also delete all the content on it (pictures, music, ...).
- The length of a filename or directory name is limited to the length specified by the FAT16/32 file systems.
- The access and response time of the content on a device can differ depending on the type or brand of the device.
- The access and response time of the content on a device will increase the more unsupported or corrupted files are on the device.

### USB Memory Device Issues

- Devices connected to the USB port of your TV must be "Mass Storage Class" compliant. If your device is not "Mass Storage Class" compliant it will not be detected by the content browser of the TV.
- The following subsets of the Mass Storage Class specification are supported:
  - The implementation of the TV is based on the "Universal Serial Bus Mass Storage Class Specification Overview" (v1.2, June 23, 2003) including all documents referenced by the document. The document can be found on the USB standardization website ([www.usb.org](http://www.usb.org)).
  - Full support of the USB Mass Storage Class Bulk-Only Transport (bInterfaceProtocol = 50h).
  - Full support of SubClass Code = 05h; SFF-8070i spec.
  - Full support of SubClass Code = 06h; SCSI transparent command set.
- For large USB memory devices, when you are in the Content Browser, it may take a long time before you can access your files.
- When using a USB portable hard disk: Due to the high power consumption of the hard disk, it is advised to use the external power supply of the portable hard disk to guarantee proper working under all conditions.

## 12. Technical specifications

PICTURE ENHANCEMENT	
Type	1080p 60Hz
Brightness	500 cd/m <sup>2</sup>
Aspect Ratio	16:9
Response Time	5 ms
Viewing Angles	178 (V) by 178 (H)
Built-in digital tuner	ATSC/QAM
Dynamic Dimming BL	Yes
SOUND ENHANCEMENT	
Mono/Stereo/BBE	Mono, Stereo, BBE
Power output (RMS Watts)	20 W
Equalizer	5 band
EASE OF USE	
Video modes	Automatic, 4:3, Movie Expand 14:9, Movie Expand 16:9, Super Zoom, Wide Screen, Unscaled
PC input	via HDMI
CONNECTIONS	
Component video input with Audio L/R	2, supporting 480i/p, 576i/p, 720p, 1080i, 1080p @24Hz-60Hz
Composite video input with audio L/R and S-Video	2
HDMI	3, ver1.3a HDMI supporting video: 480i/p, 576i/p, 720p, 1080i, 1080p @24Hz-60Hz, PC-input: up to WUXGA
Digital audio out	Yes, supporting AC-3 & PCM
Headphone	1 (on the side of TV)
USB	1 (on the side of TV)
MISCELLANEOUS	
Auto multi-voltage	110V-240V ~ , 50/60 Hz, 120V
Table Top Stand Swivel	Integrated stand without swivel

---

## 13. Index

---

### A

- Antenna, connect 7
- Audio 14
  - Alternate 14
  - Language 14
- Auto format 14
- Automatic
  - Channel installation 23
  - Volume leveling 14

---

### B

- Back connectors 6
- Batteries 7
- Blu-ray 26
- Brightness
  - Picture 13

---

### C

- Cable
  - Component 27
  - Composite 27
  - HDMI 27
  - Management 8
  - Quality comparison 27
  - S-Video 27
  - YPbPr 27
- Care
  - Environment 5
  - Screen 5
- Channels
  - Favorite list 15
  - Install 23
- Child lock
  - Lock all channels/devices 17
  - Lock one or more channel/device 17
  - PIN code 17
  - Set movie rating 18

- Set TV rating 18
- Clock 16
- Closed captions 20
- Color
  - Enhancement 13
  - Picture setting 13
  - Temperature 13
- Component cable 27
- Composite cable 27
- Configuring the TV in HDTV mode 21
- Connection
  - Antenna 7
  - Back connectors 6
  - Cable quality 27
  - DBS 7
  - Devices 28
  - Label 27
  - Overview 26
  - PC 30
  - Power cord 8
  - Set-top box 8
  - Side connectors 6
- Contrast 13
- Controls 6

---

### D

- DBS, connect 7
- Default, return to 24
- Delta volume 14
- Device, connect 28
- Disconnect power 8
- Display, native 1080 22
- Dynamic contrast 13

---

### E

- EAS 24
- Emergency alerts 24
- Environmental care 5
- Equalizer 14

---

### F

- Favorite lists 15

---

### H

- HDCP 27
- HDMI cable 27
- HDTV mode 21
- Home mode 23

---

### I

- Installation
  - Channels 23
  - First time 9

---

### L

- Label connections 27
- Language
  - Audio 14
  - Menus 23
- Location 23
- Locks. See Child lock

---

### M

- Menu
  - Language 23
  - Quick access 13
- Mode
  - HD 21
  - Home or retail store 23
  - PC 22
- Model number 5
- Movie expand 14
- Movie ratings 19

---

### N

- Noise reduction 13

---

**O**

Overview, TV 6

---

**P**

Parental control. *See* Child lock

PC mode 22

Picture

Adjust settings 13

Change format 13

PIN code 17

Power cord

Connect 8

Disconnect 8

Product information 5

---

**Q**

Quick access menu 13

---

**R**

Ratings

Movie 19

Region 20

TV 18

Recycling 5

Region ratings 20

Remote control

Advanced use 12

Basic use 6

Batteries 7

Retail store mode 23

---

**S**

Screen care 5

Screen resolution, PC mode 22

Settings 14

Set-top box, connection 8

Sharpness 13

Shift

Vertical 13

Side controls and connectors 6

---

Signal quality 23

Sleeptimer 16

Smart Mode 15

Software

Update 25

Version 25

Store mode 23

Super zoom 14

S-Video cable 27

---

**T**

Technical specifications 34

Timer

Clock 16

Sleeptimer 16

Tint 13

TV

Model number 5

Overview 6

Position 7

Ratings 18

---

**U**

Upgrade software 25

USB

Connector 26

Notes on use 33

---

**V**

Version, software 25

Vertical shift 13

Video cable 27

Video format, HD mode 21

---

**W**

Wall mount TV 7

---

**Y**

YPbPr cable 27

---

## 14. Warranty

### MAGNAVOX LIMITED WARRANTY NINETY (90) DAY LABOR / ONE (1) PARTS

#### WARRANTY COVERAGE:

MAGNAVOX warranty obligation is limited to the terms set forth below.

#### WHO IS COVERED:

Magnavox warrants the product to the original purchaser or the person receiving the product as a gift against defects in materials and workmanship as based on the date of original purchase ("Warranty Period") from an Authorized Dealer. The original sales receipt showing the product name and the purchase date from an authorized retailer is considered such proof.

#### WHAT IS COVERED:

The Magnavox warranty covers new products if a defect in material or workmanship occurs and a valid claim is received by Magnavox within the Warranty Period. At its option, Magnavox will either (1) repair the product at no charge, using new or refurbished replacement parts, or (2) exchange the product with a product that is new or which has been manufactured from new, or serviceable used parts and is at least functionally equivalent or most comparable to the original product in Magnavox current inventory, or (3) refund the original purchase price of the product.

Magnavox warrants replacement products or parts provided under this warranty against defects in materials and workmanship from the date of the replacement or repair for ninety (90) days or for the remaining portion of the original product's warranty, whichever provides longer coverage for you. When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes Magnavox property. When a refund is given, your product becomes Magnavox property.

**Note: Any product sold and identified as refurbished or renewed carries a ninety (90) day limited warranty.**

**Replacement product can only be sent if all warranty requirements are met. Failure to follow all requirements can result in delay.**

#### WHAT IS NOT COVERED - EXCLUSIONS AND LIMITATIONS:

This Limited Warranty applies only to the new products manufactured by or for Magnavox that can be identified by the trademark, trade name, or logo affixed to it. This Limited Warranty does not apply to any non-Magnavox hardware product or any software, even if packaged or sold with the product. Non-Magnavox manufacturers, suppliers, or publishers may provide a separate warranty for their own products packaged with the bundled product.

Magnavox is not liable for any damage to or loss of any programs, data, or other information stored on any media contained within the product, or any non-Magnavox product or part not covered by this warranty. Recovery or reinstallation of programs, data or other information is not covered under this Limited Warranty.

This warranty does not apply (a) to damage caused by accident, abuse, misuse, neglect, misapplication, or non-Magnavox product, (b) to damage caused by service performed by anyone other than

*This warranty gives you specific legal rights. You may have other rights which vary from state/province to state/province.*

Magnavox or Magnavox Authorized Service Location, (c) to a product or a part that has been modified without the written permission of Magnavox, or (d) if any Magnavox serial number has been removed or defaced, or (e) product, accessories or consumables sold "AS IS" without warranty of any kind by including refurbished Magnavox product sold "AS IS" by some retailers.

#### This Limited Warranty does not cover:

- Shipping charges to return defective product to Magnavox.
- Labor charges for installation or setup of the product, adjustment of customer controls on the product, and installation or repair of antenna/signal source systems outside of the product.
- Product repair and/or part replacement because of improper installation or maintenance, connections to improper voltage supply, power line surge, lightning damage, retained images or screen markings resulting from viewing fixed stationary content for extended periods, product cosmetic appearance items due to normal wear and tear, unauthorized repair or other cause not within the control of Magnavox.
- Damage or claims for products not being available for use, or for lost data or lost software.
- Damage from mishandled shipments or transit accidents when returning product to Magnavox.
- A product that requires modification or adaptation to enable it to operate in any country other than the country for which it was designed, manufactured, approved and/or authorized, or repair of products damaged by these modifications.
- A product used for commercial or institutional purposes (including but not limited to rental purposes).
- Product lost in shipment and no signature verification receipt can be provided.
- Failure to operate per Owner's Manual.

#### TO OBTAIN ASSISTANCE IN THE U.S.A., PUERTO RICO, OR U.S. VIRGIN ISLANDS...

Contact Magnavox Customer Care Center at:  
1-800-705-2000

#### TO OBTAIN ASSISTANCE IN CANADA...

1-800-661-6162 (French Speaking)  
1-800-705-2000 (English or Spanish Speaking)

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY IS THE EXCLUSIVE REMEDY FOR THE CONSUMER. MAGNAVOX SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.

Some states do not allow the exclusions or limitation of incidental or consequential damages, or allow limitations on how long an implied warranty lasts, so the above limitations or exclusions may not apply to you.

Magnavox, P.O. Box 671539, Marietta, GA. 30006-0026





Specifications are subject to change without notice.  
Trademarks are the property of their respective owners.  
© 2008 Magnavox.  
All rights reserved.

**[www.magnavox.com](http://www.magnavox.com)**

12NC: 3139 125 40192